

J. B. SALLEY  
840 WHITES FERRY RD.  
WEST MONROE, LA. 71290

## Parts List

# CHRYSLER Plymouth



First Edition  
June 1928

Effective With Car Serial HL950P

**Plymouth Motor Corporation**

*Division of Chrysler Corporation*

Detroit, Michigan, U. S. A.

J. B. SALLEY  
8410 WHITES FERRY RD.  
WEST MONROE, LA. 71291

# Parts List

CHRYSLER  
PLYMOUTH

First Edition  
June 1928

Effective With Car Serial HL950P

**Plymouth Motor Corporation**

*Division of Chrysler Corporation*  
Detroit, Michigan, U. S. A.

Price Twenty-five Cents

PRINTED IN U. S. A.

## GROUP INDEX

Group Name	Group Starts Page
Axle—Front.....	5
Axle—Rear.....	7
Body—Open Cars.....	57
Body—Closed Cars.....	63
Brake—Service.....	9
Brake—Transmission.....	13
Clutch.....	14
Cooling System.....	16
Electrical System.....	18
Engine.....	22
Exhaust System.....	28
Fenders, Running Boards and Dust Shields.....	29
Frame.....	32
Fuel System.....	34
Hood.....	37
Lamps.....	38
Oiling System.....	39
Propeller Shaft and Universal Joint.....	41
Speedometer.....	42
Springs.....	43
Steering Gear.....	45
Tools.....	48
Transmission.....	49
Wheels.....	51
Wiring.....	55

## AXLE—FRONT

## FRONT AXLE "I" BEAM

PART NAME	Per Car	Part Number
Front axle "I" beam and bushing assembly	1	40600
Front axle "I" beam bushing (upper)	2	41211
Front axle "I" beam bushing (lower)	2	42652

## STEERING KNUCKLE

Steering knuckle, right	1	40562
Steering knuckle, left	1	40563
Steering knuckle nut (see Front Wheel Bearings—Wheel Group)		
Steering knuckle pivot pin (king pin) (domestic cars)	2	42651
Steering knuckle pivot pin (king pin) (export cars)	2	42656
Steering knuckle pivot pin lock pin	2	41558
Steering knuckle pivot pin oil seal plug	4	103893
Steering knuckle pivot pin oiler	4	115076
Steering knuckle thrust bearing	2	35954
Steering knuckle thrust bearing shim (thick)	as reqd.	41611
Steering knuckle thrust bearing shim (thin)	as reqd.	41612

## STEERING KNUCKLE ARM

Steering knuckle arm, right (L. H. D.)	1	40601
Steering knuckle arm, left (L. H. D.)	1	40602
Steering knuckle arm, right (R. H. D.)	1	40724
Steering knuckle arm, left (R. H. D.)	1	40725
Key	2	120051
Steering knuckle arm nut	2	33208
Cotter pin	2	103386

## STEERING KNUCKLE TIE ROD

Tie rod assembly	1	40705
Tie rod (rod only)	1	40706
Tie rod end, right	1	40708
Tie rod end, left	1	40709
Tie rod end clamp bolt	2	109848
Nut	2	103027
Nut lockwasher	2	103322
Tie rod end ball seat	2	40707
Tie rod end ball seat spring	2	40710
Tie rod end threaded plug	2	42707
Cotter pin	2	103388
Tie rod oiler	2	115076
Tie rod ball	2	51354
Tie rod ball nut	2	50330
Cotter pin	2	103374
Tie rod ball dust cover	2	75045
Tie rod ball dust cover spring	2	75049

## AXLE—FRONT (Continued)

## DRAG LINK

PART NAME	Per Car	Part Number
Drag link assembly (domestic cars)	1	42804
Drag link assembly (L. H. D.) (export cars)	1	42810
Drag link assembly (R. H. D.)	1	43439
Drag link body (domestic cars)	1	42805
Drag link body (L. H. D.) (export cars)	1	42811
Drag link body (R. H. D.)	1	43440
Drag link ball seat (domestic cars)	4	52003
Drag link ball seat (export cars)	4	42808
Drag link ball seat spring (domestic cars)	2	42806
Drag link ball seat spring (export cars)	4	42807
Drag link end plug	2	52006
Cotter pin	2	103388
Drag link oiler (front)	1	52347
Drag link oiler (rear)	1	115076
Drag link ball (front axle end)	1	51354
Drag link ball nut	1	50330
Cotter pin	1	103374
Drag link ball dust cover (front axle end)	1	53094
Drag link ball dust cover washer	1	53095
Drag link ball dust cover spring	1	50332
Drag link ball dust cover (inner) (steering gear end) (domestic cars)	1	34611
Drag link ball dust cover (inner) (steering gear end) (export cars)	2	43947
Drag link ball dust cover (outer) (steering gear end)	1	34610
Drag link ball dust cover bolt	1	34773
Nut	1	105614

## STEERING GEAR ARM

Steering gear arm (between gear and drag link) (L. H. D.)	1	42878
Steering gear arm (between gear and drag link) (R. H. D.)	1	
Steering gear arm nut	1	42880
Steering gear arm nut lockwasher	1	103335

## AXLE—REAR

## REAR AXLE HOUSING

PART NAME	Per Car	Part Number
Housing	1	42939
Housing cover	1	42350
Screw	10	106284
Screw lockwasher	10	103321
Drain plug	1	103869
Housing cover gasket	1	41274
Rear axle shock absorber strap anchor	2	79710
For brake parts on the rear axle (see Service Brake Group)		

## DIFFERENTIAL

Differential and carrier assembly (4.3 to 1 ratio)	1	43109
Differential carrier and cap assembly	1	43130
Differential carrier gasket	1	41295
Differential carrier to housing screw	10	50443
Lockwasher	10	103321
Differential carrier cap screw	4	41286
Lockwasher	4	118975
Differential carrier cap screw lockwire	2	41287
Differential and drive gear assembly (4.3 to 1 ratio)	1	43113
Differential case	1	43114
Differential gear	2	43175
Differential pinion	2	43176
Differential pinion shaft	1	43224
Differential pinion shaft lock screw	1	41278
Lockwasher	1	103320
Drive gear (4.3 to 1 ratio)	1	43115
Drive gear rivet	10	50412
Differential bearing cone and rollers	2	40417
Differential bearing cup	2	40418
Differential bearing adjuster	2	41283
Differential bearing adjuster lock	2	41284
Differential bearing adjuster lock screw	2	41285

## DRIVE PINION

Drive pinion (4.3 to 1 ratio)	1	43104
Drive pinion nut	1	43411
Washer	1	50652
Cotter pin	1	103386
Drive pinion spider	1	43118
Key	1	51106
Drive pinion bearing cage assembly	1	43227
Drive pinion bearing cage stud	2	43221
Nut	2	103026
Nut lockwasher	2	103321
Drive pinion bearing cage screw	4	51170
Lockwasher	4	103321

AXLE—REAR (Continued)

DRIVE PINION (Continued)

PART NAME	Per Car	Part Number
Drive pinion front bearing cone and rollers	1	43129
Drive pinion front bearing cup	1	53535
Drive pinion rear bearing cone and rollers	1	53534
Drive pinion rear bearing cup	1	53535
Drive pinion bearing oil seal assembly	1	43123
Drive pinion bearing oil seal retainer gasket	1	43142
Drive pinion bearing spacer	1	43127
Drive pinion adjusting shim (.0125")	2	43124
Drive pinion adjusting shim (.015")	2	43125
Drive pinion adjusting shim (.035")	2	43126
Drive pinion bearing adjusting shim (.004")	2	43257
Drive pinion bearing adjusting shim (.005")	2	43159
Drive pinion bearing adjusting shim (.010")	2	43158
Drive pinion bearing adjusting shim (.015")	2	43157

DRIVE SHAFT

Drive shaft (axle shaft)	2	43048
Drive shaft key	2	41110
Drive shaft nut	2	53553
Cotter pin	2	103398
Drive shaft nut washer	2	50652
Drive shaft oil washer assembly	2	43049
Drive shaft oil washer (felt)	2	43050
Drive shaft bearing cone and rollers	4	43033
Drive shaft bearing cup	4	43032
Drive shaft bearing shim	4	43057
Drive shaft bearing oil seal assembly	2	43053
Drive shaft bearing oil seal (leather)	2	79449
Drive shaft bearing oil seal retainer gasket	2	43004
Drive shaft bearing grease plug	2	79459

BRAKE—SERVICE

BRAKE PEDAL

PART NAME	Per Car	Part Number
Brake pedal and bushing assembly (L. H. D.)	1	43101
Brake pedal and bushing assembly (R. H. D.)	1	43151
Stop screw	1	102458
Stop screw nut	1	103079
Brake pedal bushing	1	50586
Brake and clutch pedal stop (L. H. D.)	1	41154
Screw	2	100121
Screw lockwasher	2	114605
Brake pedal pull-back spring (L. H. D.)	1	51352
Brake pedal pull-back spring (R. H. D.)	1	76321
Brake pedal pull-back spring clip (R. H. D.)	4	9013
Brake and clutch pedal pull-back spring bracket (L. H. D.)	1	42606
Brake pedal bracket (R. H. D.) (see Master Cylinder Section)		
Brake pedal shaft (R. H. D.)	1	52175
Pin	1	112036
Brake pedal shaft spring (R. H. D.)	1	50434
Washer	1	50410
Washer cotter pin	1	103385

BRAKE SUPPORTS

Front wheel brake support and adjusting pin assembly	2	43695
Front wheel brake support screw	8	55687
Lockwasher	8	103322
Front wheel brake shoe anchor bolt bracket	2	43020
Rivet	6	102678
Front wheel brake grease shield	2	43002
Front wheel brake grease shield gasket	2	43220
Front wheel brake grease shield screw	4	113970
Nut	2	102624
Lockwasher	4	114604
Rear wheel brake support and adjusting pin assembly	2	43694
Rear wheel brake support to axle bolt	12	76871
Nut	12	73923
Nut lockwasher	12	103321
Rear wheel brake shoe anchor bolt bracket	2	43021
Rivet	6	102678

BRAKE SHOES

Wheel brake shoe and facing assembly (front half)	4	43008
Wheel brake shoe and facing assembly (rear half)	4	44597
Wheel brake shoe guide pin	8	43013
Wheel brake shoe anchor bolt	8	43012
Nut	8	120371
Nut lockwasher	8	103323
Wheel brake shoe return spring	4	42944
Wheel brake shoe adjusting pin and washer assembly	8	77532
Wheel brake shoe adjusting cam	8	79318
Wheel brake shoe adjusting cam spring	8	77535
Wheel brake shoe bearing plate	16	43019

## BRAKE—SERVICE (Continued)

## MASTER CYLINDER

PART NAME	Per Car	Part Number
Wheel brake drum (see Wheel Group)	1	43094
Master cylinder assembly (L. H. D.)	1	79444
Master cylinder assembly (R. H. D.)	1	43154
Master cylinder and brake pedal bracket (R. H. D.)	4	106330
Screw (to frame)	4	103321
Screw lockwasher	4	103321
Master cylinder fastening screw, long (L. H. D.)	1	106331
Master cylinder fastening screw, short (L. H. D.)	2	100134
Master cylinder fastening screw (R. H. D.)	3	100134
Master cylinder fastening screw lockwasher	3	103321
Master cylinder body and head assembly (L. H. D.)	1	43095
Master cylinder body and head assembly (R. H. D.)	1	79381
Master cylinder piston	1	79362
Master cylinder piston push rod	1	79372
Master cylinder piston push rod end	1	79383
Master cylinder piston push rod end pin (L. H. D.)	1	79394
Cotter pin	1	107762
Master cylinder piston push rod end pin (R. H. D.)	1	114785
Cotter pin	1	103373
Master cylinder piston push rod end check nut	1	114495
Master cylinder piston cup	1	77043
Master cylinder piston return spring	1	79374
Master cylinder piston stop	1	79364
Master cylinder piston stop lock wire	1	79376
Master cylinder secondary cup	1	79379
Master cylinder secondary cup expander	1	79371
Master cylinder secondary cup retainer	1	79367
Master cylinder inlet valve	1	77063
Master cylinder head inlet valve seat	1	79369
Master cylinder boot	1	79373
Master cylinder boot strap (large)	1	79361
Master cylinder boot strap (small)	1	79363
Signal lamp switch (see Electrical System Group)		

## MASTER CYLINDER SUPPLY TANK

Master cylinder supply tank and clamp assembly	1	79354
Fastening bolt	4	100426
Fastening bolt lockwasher	4	114604
Master cylinder supply tank clamp and bolt assembly	2	79358
Master cylinder supply tank clamp bolt and nut	2	121720
Nut lockwasher	2	103318
Master cylinder supply tank filler cap	1	43403
Master cylinder supply tank filler cap retainer	1	43404
Master cylinder supply tank filler cap gasket	1	43405

## BRAKE—SERVICE (Continued)

## MASTER CYLINDER SUPPLY TANK (Continued)

PART NAME	Per Car	Part Number
Master cylinder supply tank outlet	1	79360
Master cylinder supply tank outlet gasket	1	51396
Master cylinder supply tank outlet nut	1	103028

## WHEEL CYLINDER

Wheel cylinder assembly	4	79190
Fastening screw	8	106324
Fastening screw lockwasher	8	103320
Wheel cylinder piston	8	79218
Wheel cylinder piston cup	8	77526
Wheel cylinder piston cup spring	4	77520
Wheel cylinder bleeder screw	4	77671
Cap screw	4	115623
Cap screw lockwasher	4	103319
Wheel cylinder boot	8	77529

## TUBES AND CONNECTIONS

Master cylinder to supply tank tube assembly (L. H. D.)	1	43229
Master cylinder to supply tank tube assembly (R. H. D.)	1	43231
Union nut	2	51494
Master cylinder to frame tee tube assembly (L. H. D.)	1	43233
Master cylinder to frame tee tube assembly (R. H. D.)	1	43235
Union nut	2	51494
Frame tee to front hose connection tube assembly, right	1	43237
Frame tee to front hose connection tube assembly, left	1	43239
Union nut	4	51480
Frame tee to rear hose connection tube assembly	1	43241
Union nut	2	51480
Rear axle brake tube assembly, right	1	44322
Rear axle brake tube assembly, left	1	44323
Union nut	4	51480
Rear axle brake tube clip, center	2	78351
Rear axle brake tube clip, right	1	40751
Screw	1	107624
Screw lockwasher	1	103319
Wheel brake hose assembly	3	54686
Master cylinder inlet fitting	1	79377
Master cylinder inlet fitting gasket	1	79366
Master cylinder outlet nipple	1	51493
Master cylinder outlet nipple gasket	1	51396
Brake tube frame bracket, front	2	74163
Bolt	4	100001
Bolt nut	4	103024
Bolt nut lockwasher	4	114604
Brake tube frame bracket, rear	1	79776
Rivet	3	104097

**BRAKE—SERVICE (Continued)**  
**TUBES AND CONNECTIONS (Continued)**

PART NAME	Per Car	Part Number
Brake tube frame tee.....	1	43208
Bolt.....	1	100013
Bolt nut.....	1	103025
Bolt nut lockwasher.....	1	114605
Rear axle brake tube tee.....	1	40746
Nut.....	1	103027
Nut lockwasher.....	1	114607
Brake tube hose union.....	3	40730
Nut.....	3	103027
Nut lockwasher.....	2	79191
Front wheel cylinder inlet connection.....	2	43211
Rear wheel cylinder inlet connection.....	2	42972
Wheel cylinder inlet connection pilot hole cover.....	2	42972
Wheel cylinder inlet connection gasket.....	4	79192
Wheel cylinder inlet connection bolt.....	4	79193
Wheel cylinder inlet connection bolt gasket.....	4	79194

**BRAKE—TRANSMISSION**

**BRAKE BAND**

PART NAME	Per Car	Part Number
Brake band assembly.....	1	41235
Brake band lining.....	1	41237
Rivet.....	14	102516
Brake band bracket (upper).....	1	41238
Brake band bracket (lower).....	1	41239
Rivet.....	6	112619
Brake band anchor.....	1	41240
Rivet.....	4	112619
Brake band anchor spring.....	1	33261
Brake band anchor screw.....	1	33268
Brake band anchor screw lockwire.....	1	14155
Brake band guide bolt.....	1	117286
Nut.....	2	109084
Lockwasher.....	1	103319
Brake operating lever.....	1	41242
Brake release spring.....	2	56797
Brake adjusting bolt.....	1	41246
Brake adjusting bolt nut.....	1	41247
Brake adjusting bolt bracket.....	1	41248
Brake adjusting bolt clevis pin.....	1	41249
Cotter pin.....	1	103406

**BRAKE SUPPORT**

Brake support.....	1	42314
Screw.....	2	106331
Screw lockwasher.....	2	103321

**BRAKE ROD**

Brake rod.....	1	43024
Cotter pin.....	1	107762
Brake rod clevis pin.....	1	41251
Cotter pin.....	1	107762

**BRAKE DRUM**

Transmission brake drum.....	1	41264
------------------------------	---	-------

**HAND BRAKE LEVER**

Hand brake lever assembly.....	1	42372
Hand brake lever latch rod.....	1	42374
Hand brake lever button.....	1	41162
Hand brake lever spring.....	1	50094
Hand brake lever washer.....	1	50095
Hand brake lever latch.....	1	41159
Rivet.....	1	102689
Hand brake lever fulcrum pin.....	1	41165
Hand brake lever sector.....	1	43023
Brew.....	2	42491
Brew lockwasher.....	2	103320



## CLUTCH

## CLUTCH HOUSING

PART NAME	Per Car	Part Number
Clutch housing and bushing assembly	1	41603
Screw (to transmission case)	4	100146
Screw lockwasher	4	103322
Screw (to flywheel housing)	8	100134
Screw lockwasher	8	103321
Clutch housing bushing (release fork bushing)	1	50519
Clutch housing hand hole cover	1	41149
Screw	2	107627
Screw lockwasher	2	103319
Clutch housing to flywheel housing dowel	2	51078

## CLUTCH PARTS

Clutch driving disc, facing and hub assembly	1	41207
Clutch driving disc facing (thin)	4	41185
Clutch driving disc facing (thick)	4	41186
Clutch driving disc facing rivet	20	41206
Clutch pressure plate and stud assembly	1	42233
Clutch back plate	1	40939
Clutch back plate screw	6	40940
Lockwasher	6	103320
Clutch spring	6	41205
Clutch spring cup	6	41198

## CLUTCH RELEASE PARTS

Clutch release lever	3	42229
Clutch release lever clevis pin	3	41200
Cotter pin	3	103372
Clutch release lever spring	3	41201
Clutch release lever adjusting screw	3	41195
Clutch release lever adjusting screw seat and ball assembly	3	41932
Clutch release lever adjusting stud	3	42232
Clutch release lever adjusting stud pin	3	41196
Clutch release bearing assembly	1	41208
Clutch release bearing oiler	1	115076
Clutch release bearing sleeve	1	41150
Clutch release bearing sleeve guide	1	41151
Lockwasher	1	115548
Clutch release bearing sleeve pull-back spring	1	53388
Clutch release fork (L. H. D.)	1	56811
Clutch release fork (R. H. D.)	1	56989
Clutch release fork thrust washer (R. H. D.)	1	56990
Screw	1	51487
Screw lockwasher	1	103321
Clutch release fork flange and bushing assembly	1	56812

## CLUTCH (Continued)

## CLUTCH RELEASE PARTS (Continued)

PART NAME	Per Car	Part Number
Clutch release fork flange screw	2	100122
Lockwasher	2	103320
Clutch release fork flange bushing	1	50586

## CLUTCH PEDAL

Clutch pedal (L. H. D.)	1	43097
Clutch pedal (R. H. D.)	1	41345
Stop screw	1	102458
Stop screw nut	1	103079
Clutch pedal adjusting collar	1	33106
Set screw	2	102458
Set screw nut	2	103079
Clamp screw	1	51171
Clamp screw lockwasher	1	103321
Key	1	103907
Clutch pedal pull-back spring (L. H. D.)	1	51352
Clutch pedal pull-back spring bracket (L. H. D.) (see Brake Pedal Section)		
Clutch pedal pull-back spring (R. H. D.)	1	55825
Clutch pedal pull-back spring bracket (R. H. D.)	1	41517
Clutch and brake pedal stop (L.H.D.) (see Brake Pedal Section)		

## COOLING SYSTEM

## RADIATOR

PART NAME	Per Car	Part Number
Radiator assembly.....	1	43172
Drain cock.....	1	51762
Core assembly.....	1	43046
Core support stud.....	2	38942
Nut.....	2	120370
Plain washer.....	2	74697
Lockwasher.....	2	103322
Core support shim.....	4	52442
Core lower support anti-squeak.....	1	43073
Shell assembly.....	1	79427
Fastening bolt and nut.....	10	121372
Fastening bolt lockwasher.....	10	114604
Radiator hood rod socket—upper half.....	1	79672
Radiator hood rod socket—lower half.....	1	79673
Shell hood rod socket bolt.....	2	39093
Nut.....	2	120614
Lockwasher.....	2	114603
Lacing.....	2	79246
Rivet.....	22	104448
Medallion.....	1	42993
Screw.....	1	100957
Screw lockwasher.....	1	114602
Washer.....	2	44090
Filler cap.....	1	43137
Filler cap gasket.....	1	79277
Filler cap shim.....	1	79994

## RADIATOR BRACE ROD

Radiator brace rod.....	2	43290
Nut.....	4	103025
Lockwasher.....	2	114605
Bolt.....	1	109847
Bolt nut.....	1	103026
Plain washer.....	2	103341
Lockwasher.....	1	103321

## RADIATOR HOSE

Radiator inlet hose.....	1	43287
Clamp.....	2	105483
Radiator outlet hose.....	2	30558
Clamp.....	4	105483
Radiator outlet hose tube.....	1	43286

## STARTING CRANK HOLE COVER

Starting crank hole cover assembly.....	1	43139
---	---	-------

## COOLING SYSTEM (Continued)

## FAN

PART NAME	Per Car	Part Number
Fan blade.....	1	37511
Screw.....	4	106324
Screw lockwasher.....	4	103320

## FAN AND GENERATOR PULLEY

Fan and generator drive pulley (lower).....	1	35671
Key.....	1	103906
Fan and generator pulley (upper).....	1	37512
Nut.....	1	103027
Plain washer.....	1	103342
Lockwasher.....	1	110405
Key.....	1	103905

## FAN AND GENERATOR DRIVE BELT

Fan and generator drive belt.....	1	30567
-----------------------------------	---	-------

## ELECTRICAL SYSTEM

## IGNITION SWITCH AND LOCK

PART NAME	Per Car	Part Number
Ignition switch lock, cables and grommets assembly (with two keys) . . . . .	1	42689
Ignition switch lock cylinder (with two keys) . . . . .	1	42408
Keys (specify key serial number) . . . . .	2	40472
Ignition switch and lock mounting frame . . . . .	1	78898
Fastening bolt . . . . .	2	110382
Fastening bolt nut . . . . .	2	114769
Fastening bolt nut lockwasher . . . . .	2	115545
Clamping bolt and nut . . . . .	1	101280
Clamping bolt nut lockwasher . . . . .	1	115545

## LIGHTING SWITCH

Lighting switch (see Steering Gear Group)

## INSTRUMENT LAMP SWITCH

Instrument lamp switch . . . . .	1	79498
Mounting screw . . . . .	2	107073
Terminal screw . . . . .	2	100957
Terminal screw lockwasher . . . . .	2	115544

## STARTER SWITCH

Starter switch assembly (Remy 404-X) . . . . .	1	43072*
Fastening screw . . . . .	2	106324
Fastening screw lockwasher . . . . .	2	103320

## SIGNAL LAMP SWITCH

Signal lamp switch . . . . .	1	74185
Terminal screw . . . . .	2	74186
Terminal screw lockwasher . . . . .	2	115543

## AMMETER

Ammeter, oil gauge and instrument lamp housing . . . . .	1	42669
Mounting bolt . . . . .	2	117476
Mounting bolt nut . . . . .	2	114769
Mounting bolt nut lockwasher . . . . .	2	115545
Fuse . . . . .	1	106653
Fuse block terminal stud nut . . . . .	2	113103
Lockwasher . . . . .	2	115544
Ammeter terminal stud nut . . . . .	2	112432
Lockwasher . . . . .	2	115545

## HORN

Horn assembly (all cars except Germany) . . . . .	1	A875**
Horn assembly (for Germany only) (EA-Autovocce) . . . . .	1	75081**

\*Domestic service by United Motors Service, Inc., Detroit, Mich.  
 \*Overseas service by Overseas Motor Service Corp., New York, N. Y., U. S. A.  
 \*\*Domestic service by Sparks-Withington Co., Jackson, Mich.  
 \*\*Overseas service by Plymouth Motor Corp., Detroit, Mich., U. S. A.

## ELECTRICAL SYSTEM (Continued)

## HORN (Continued)

PART NAME	Per Car	Part Number
Horn attaching bolt nut . . . . .	2	52716
Lockwasher . . . . .	2	106498
Horn terminal nut (all cars except Germany) . . . . .	2	115998
Horn terminal nut (for Germany only) . . . . .	2	110922
Lockwasher . . . . .	2	106496
Horn bracket (all cars except Germany) . . . . .	1	37559
Horn bracket (for Germany only) . . . . .	1	42249
Horn button (see Steering Gear Group)		

## IGNITION COIL

Ignition coil assembly (525-E) . . . . .	1	56888*
Fastening bolt . . . . .	3	100426
Fastening bolt lockwasher . . . . .	3	115547

## DISTRIBUTOR

Distributor assembly (Remy 630-A) . . . . .	1	43971*
Distributor base to gear case screw . . . . .	2	100019
Lockwasher . . . . .	2	103320
Distributor base to gear case gasket . . . . .	1	30872
Distributor locking base . . . . .	1	42690
Distributor locking clip . . . . .	1	42691
Distributor connecting link . . . . .	1	42699
Sleeve . . . . .	1	42700
Distributor terminal insulating block . . . . .	1	42694
Distributor terminal insulator . . . . .	1	42695
Distributor terminal insulation washer . . . . .	1	42697
Distributor terminal bolt . . . . .	1	42692
Nut . . . . .	1	42693
Washer . . . . .	1	42698
Bushing . . . . .	1	42696

## GENERATOR

Generator and cutout assembly (Remy No. 947-B) . . . . .	1	41026*
Cutout terminal screw . . . . .	2	13186
Generator drive pulleys (see Fan Section—Cooling System Group)		

## GENERATOR CRADLE

Generator cradle and strap assembly . . . . .	1	42302
Generator cradle (base only) . . . . .	1	42304
Fastening stud . . . . .	2	41806
Fastening stud nut . . . . .	2	103030
Fastening stud nut plain washer . . . . .	2	11056
Fastening stud nut lockwasher . . . . .	2	103325

\*Domestic service by United Motors Service, Inc., Detroit, Mich.  
 \*Overseas service by Overseas Motor Service Corp., New York, N. Y., U. S. A.

## ELECTRICAL SYSTEM (Continued)

## GENERATOR CRADLE (Continued)

PART NAME	Per Car	Part Number
Generator cradle strap.....	1	42306
Bolt.....	2	100026
Bolt nut.....	2	103026
Bolt nut lockwasher.....	2	103321

## STARTING MOTOR

Starting motor assembly (Remy 714-J).....	1	41061*
Attaching screw.....	2	100147
Attaching screw lockwasher.....	2	103322

## SPARK CONTROL

Spark control button and wire.....	1	42673
Spark control guide and tube.....	1	42674
Mounting nut.....	1	70779
Mounting nut lockwasher.....	1	110730
Magneto spark control wire tube support.....	1	43429
Magneto spark control wire tube support clamp bolt and nut.....	1	115133
Magneto spark control wire tube support clamp lockwasher.....	1	114602
Clamp.....	1	54731
Clamp bolt and nut.....	1	101280
Clamp bolt nut lockwasher.....	1	114603
Clip.....	1	43974
Bracket.....	1	43973
Bracket clip.....	1	54731
Bracket clip bolt and nut.....	1	101280
Bracket clip bolt nut lockwasher.....	1	106497

## SPARK PLUG

Spark plug.....	4	79551
Gasket.....	4	105456
Terminal nut.....	4	72758

## STORAGE BATTERY

Storage battery (domestic and Canada) (Willard W. R.-13).....	1	40475**
Storage battery (export only) (Willard C. W. R.-15).....	1	76563**
Battery support (see Frame Group)		

## MAGNETO (R. H. D.)

Magneto assembly.....	1	39324
Fastening screw (short).....	2	100133
Fastening screw (long).....	2	106330
Lockwasher.....	4	103321

\*Domestic service by United Motors Service, Inc., Detroit, Mich.

\*\*Overseas service by Overseas Motor Service Corp., New York, N. Y., U. S. A.

\*\*\*Domestic and overseas service by the Willard Storage Battery Co., Cleveland, Ohio, U. S. A.

## ELECTRICAL SYSTEM (Continued)

## MAGNETO BRACKET (R. H. D.)

PART NAME	Per Car	Part Number
Magneto bracket.....	1	30524
Fastening bolt.....	3	100032
Fastening bolt nut.....	3	103025
Plain washer.....	3	11289
Lockwasher.....	3	108580
Magneto bracket gasket.....	1	30525

## MAGNETO DRIVE (R. H. D.)

Magneto drive gear.....	1	42297
Hub.....	1	42116
Key.....	1	106749
Nut.....	1	41964
Washer.....	1	34643
Lockwasher.....	1	34630
Magneto drive gear felt washer.....	1	30526
Magneto drive gear felt washer retainer.....	1	30527
Screw.....	3	110500
Screw lockwasher.....	3	106497
Magneto oil deflector.....	1	42117

## ENGINE

## CYLINDER BLOCK

PART NAME	Per Car	Part Number
Cylinder block and valve stem guide assembly	1	42733
Tappet oil hole plug	8	44246
Cylinder block core hole plug	2	6130
Cylinder head	1	42721
Cylinder head stud	14	42753
Nut	14	103027
Cylinder head gasket	1	42716

## CYLINDER WATER OUTLET AND INLET ELBOWS

Water outlet elbow	1	37986
Screw	2	106330
Screw lockwasher	2	103321
Water outlet elbow gasket	1	37987
Water inlet pipe	1	35968
Water inlet pipe stud	2	41697
Nut	2	103025
Lockwasher	2	108579
Water inlet pipe gasket	1	5109

## OIL FILLER (BREATHER)

Breather pipe	1	41079
Breather pipe cap	1	41082

## CRANKCASE VENTILATOR OUTLET

Crankcase ventilator outlet assembly	1	40520
--------------------------------------	---	-------

## GEAR CASE

Gear case and front bearing assembly	1	41036
Gear case and front bearing assembly (R. H. D. magneto ignition)	1	41418
Fastening screw	6	106330
Fastening screw lockwasher (split)	4	103321
Fastening screw lockwasher (flat)	2	115549
Oil hole plug	1	42889
Gear case gasket	1	42181
Gear case cover assembly	1	41072
Gear case cover assembly (R. H. D. magneto ignition)	1	41338
Fastening screw (short)	8	100138
Fastening screw (long)	1	100139
Fastening screw lockwasher	9	103321
Gear case cover dowel pin	2	35782
Gear case cover oil retainer (felt)	1	34804
Gear case cover oil retainer cap	1	34803
Screw	2	107627
Screw lockwasher	2	114604
Gear case cover gasket	1	30515
Gear case cover gasket (R. H. D. magneto ignition)	1	30518

## ENGINE (Continued)

## CRANKSHAFT

PART NAME	Per Car	Part Number
Crankshaft and pilot bushing assembly	1	41090
Crankshaft bushing for transmission drive pinion	1	53298
Crankshaft starting jaw	1	31025
Crankshaft starting jaw washer (thick)	as reqd.	11339
Crankshaft starting jaw washer (thin)	as reqd.	34327
Crankshaft starting jaw lockwasher	1	31053

## CRANKSHAFT BEARINGS

Crankshaft front bearing bushing	1	41608
Crankshaft front bearing bushing (.010" undersize)	1	42066
Pin	1	10063
Crankshaft center bearing bushing (upper)	1	41028
Crankshaft center bearing bushing (lower)	1	41029
Crankshaft center bearing bushing (upper) (.010" undersize)	1	42067
Crankshaft center bearing bushing (lower) (.010" undersize)	1	42068
Pin	1	13147
Dowel	1	31149
Crankshaft rear bearing bushing (upper)	1	31048
Crankshaft rear bearing bushing (lower)	1	31049
Crankshaft rear bearing bushing (upper) (.010" undersize)	1	42069
Crankshaft rear bearing bushing (lower) (.010" undersize)	1	42070
Pin	1	10128
Crankshaft rear lower bearing drain pipe	1	39101
Crankshaft rear lower bearing drain pipe clip	1	39102
Screw	1	100284
Screw lockwasher	1	103320

## CRANKSHAFT BEARING CAP AND SUPPORT

Crankshaft center bearing cap	1	31028
Crankshaft center bearing cap screw	2	10539
Crankshaft center bearing cap screw lock	2	31033
Crankshaft center bearing cap screw dowel	2	41701
Crankshaft rear bearing support assembly	1	39108
Fastening screw	6	106330
Fastening screw lockwasher	6	103321
Clamp bolt	2	10513
Clamp bolt nut	2	103047
Clamp bolt cotter pin	2	103374

## CAMSHAFT

Camshaft	1	34544
Camshaft front bearing assembly	1	A659
Camshaft front bearing oil seal (cork)	1	39075
Camshaft rear bearing assembly	1	A660
Camshaft rear bearing oil seal (cork)	1	37837

## ENGINE (Continued)

## CAMSHAFT (Continued)

PART NAME	Per Car	Part Number
Camshaft bearing lock screw	2	41699
Lockwasher	2	108580
Camshaft center bearing oil tube assembly	1	42884
Elbow	1	115668
Nut	2	115680
Sleeve	2	120488

## TIMING GEARS

Crankshaft gear	1	42295
Key	1	103906
Crankshaft gear lock nut	1	31024
Crankshaft gear lock nut lock	1	31052
Crankshaft gear oil seal	1	30987
Camshaft gear	1	42294
Key	1	114813
Camshaft gear nut	1	5121
Camshaft gear nut lockwasher	1	41974
Camshaft gear collar	1	37846

## CONNECTING ROD

Connecting rod assembly	1	A754*
Connecting rod assembly (.010" undersize)	1	42085
Connecting rod cap bolt	8	40527
Connecting rod cap bolt nut	8	77345
Cotter pin	8	103373

## PISTON

Piston (standard)	4	37215
Piston (.003" oversize)	4	37515
Piston (.005" oversize)	4	37516
Piston (.010" oversize)	4	37517
Piston (.015" oversize)	4	37518
Piston (.020" oversize)	4	37519
Piston (.023" oversize)	4	37520
Piston (.025" oversize)	4	37521
Piston (.030" oversize)	4	37514
Piston (.035" oversize)	4	73350
Piston (.040" oversize)	4	73351
Piston ring (upper) (standard)	4	30288
Piston ring (upper) (.005" oversize)	4	34034
Piston ring (upper) (.010" oversize)	4	30657
Piston ring (upper) (.015" oversize)	4	34036
Piston ring (upper) (.020" oversize)	4	31003
Piston ring (upper) (.025" oversize)	4	34038

\*Connecting rods may be returned for reabbtitting. A price of \$2.50 per rod is made. Only rods in serviceable condition will be accepted.

ENGINE (Continued)  
PISTON (Continued)

PART NAME	Per Car	Part Number
Piston ring (upper) (.030" oversize)	4	34040
Piston ring (upper) (.035" oversize)	4	73352
Piston ring (upper) (.040" oversize)	4	73353
Piston ring (center) (standard)	4	30318
Piston ring (center) (.005" oversize)	4	34035
Piston ring (center) (.010" oversize)	4	30658
Piston ring (center) (.015" oversize)	4	34037
Piston ring (center) (.020" oversize)	4	31004
Piston ring (center) (.025" oversize)	4	34039
Piston ring (center) (.030" oversize)	4	34041
Piston ring (center) (.035" oversize)	4	73354
Piston ring (center) (.040" oversize)	4	73355
Piston ring (lower) (standard)	4	37841
Piston ring (lower) (.005" oversize)	4	37889
Piston ring (lower) (.010" oversize)	4	37884
Piston ring (lower) (.015" oversize)	4	37890
Piston ring (lower) (.020" oversize)	4	37891
Piston ring (lower) (.025" oversize)	4	37892
Piston ring (lower) (.030" oversize)	4	37893
Piston ring (lower) (.035" oversize)	4	73356
Piston ring (lower) (.040" oversize)	4	73357
Piston pin	4	30321
Piston pin (.003" oversize)	4	73075
Piston pin (.005" oversize)	4	73083
Piston pin (.008" oversize)	4	73173
Piston pin clamp screw	4	600
Lockwasher	4	108580

## VALVE AND TAPPET

Intake valve	4	42705
Exhaust valve	4	42331
Valve stem guide	8	37213
Valve spring	8	42719
Valve spring retainer	8	42734
Pin	8	103707
Valve tappet	8	42115
Valve tappet (.008" oversize)	8	43952
Valve tappet (.030" oversize)	8	43953
Valve tappet (.060" oversize)	8	43954
Valve tappet adjusting screw	8	5067
Nut	8	103054

## VALVE SPRING COVER

Valve spring cover plate	1	40525
Valve spring cover plate stud	2	41698
Nut	2	103024
Plain washer	2	103339
Valve spring cover plate stud nut gasket	2	39076
Valve spring cover plate gasket	1	30327

## ENGINE (Continued)

## FLYWHEEL

PART NAME	Per Car	Part Number
Flywheel	1	42888
Flywheel bolt	4	31027
Nut	4	103027
Lockwasher	4	114607

## FLYWHEEL HOUSING

Flywheel housing	1	43131
Fastening screw	6	100134
Fastening screw lockwasher	6	108580
Flywheel housing gasket	1	30329

## INTAKE AND EXHAUST MANIFOLD

Intake manifold	1	42557
Exhaust manifold	1	42223
Exhaust manifold stud	2	42224
Exhaust manifold stud nut	2	103026
Lockwasher	2	108580
Manifold end gasket	4	5112
Manifold center gasket	2	37210
Manifold ferrule	4	5113
Manifold crab	2	5114
Manifold crab stud	2	41695
Nut	2	103026
Nut lockwasher	2	103321

## ENGINE SUPPORT

Front support insulator plate	1	43464
Screw	4	100493
Front support insulator	1	43465
Screw	4	100133
Screw lockwasher	4	103320
Engine rear support bracket and shock insulator assembly, right	1	43945
Engine rear support bracket and shock insulator assembly, left	1	43946
Bolt (to engine)	4	100052
Bolt nut	4	103028
Bolt nut lockwasher	4	103323
Bolt (to frame)	8	100025
Bolt nut	8	103026
Bolt nut lockwasher	8	115549
Engine rear support bracket, right	1	43484
Engine rear support bracket, left	1	43485
Rivet (to insulator)	8	104112
Engine rear support shock insulator assembly	2	43457

## ENGINE (Continued)

## IMPULSE NEUTRALIZER (DASH TO ENGINE)

PART NAME	Per Car	Part Number
Dash impulse neutralizer assembly	1	79489
Dash impulse neutralizer shoe assembly	1	79464
Dash impulse neutralizer shoe plate	1	79487
Dash impulse neutralizer spring	2	70765
Dash impulse neutralizer cover	1	79486
Rivet	4	79488
Dash impulse neutralizer to dash screw	4	100376
Lockwasher	4	114604
Dash impulse neutralizer connecting link	1	43092
Dash impulse neutralizer connecting bolt	1	121661
Nut	1	120368
Lockwasher	1	120214

## EXHAUST SYSTEM

## MUFFLER

PART NAME	Per Car	Part Number
Muffler assembly	1	42758
Muffler support clip (inner)	1	41596
Muffler support clip (outer)	1	41600
Muffler rear support bolt	1	100014
Nut	1	103025
Lockwasher	1	103320

## MUFFLER TAIL PIPE

Muffler tail pipe	1	43082
Muffler tail pipe clamp	1	42761
Bolt	1	106325
Bolt nut	1	114771
Muffler tail pipe support bracket	1	79578
Bolt	1	100013
Bolt nut	1	103025
Bolt nut lockwasher	1	115548
Muffler tail pipe support bracket clamp	1	43083
Bolt	1	100015
Bolt nut	1	103025
Bolt nut lockwasher	1	115548

## EXHAUST PIPE

Exhaust pipe	1	43209
Exhaust pipe flange	1	41057
Bolt	2	100029
Bolt nut	2	114547
Exhaust pipe flange gasket	1	41058
Exhaust pipe support	1	43210
Bolt	2	100013
Bolt nut	2	103025
Bolt lockwasher	2	114605
Clamp bolt	1	100014
Clamp bolt nut	1	103025
Clamp bolt lockwasher	1	114605

## FENDERS, RUNNING BOARDS AND DUST SHIELDS

## FRONT FENDER

PART NAME	Per Car	Part Number
Front fender, right	1	43088
Front fender, left	1	43089
Front fender, right (with tire pocket)	1	43168
Front fender, left (with tire pocket)	1	43169
Rivet (apron to support)	2	102677
Front fender support, right	1	43408
Front fender support, left	1	43409
Front fender support to frame bolt	6	100050
Nut	6	103028
Lockwasher	6	103323
Front fender support rear, right	1	44328
Front fender support rear, left	1	44329
Front fender rear support brace	2	44413
Bolt (to support)	4	100018
Bolt nut	4	103025
Bolt nut lockwasher	4	103320
Plain washer	8	106262
Front fender to splash guard bolt and nut	10	101292
Plain washer	20	103339
Lockwasher	20	114604
Front fender to running board bolt and nut	6	101292
Plain washer	12	103339
Lockwasher	12	114604
Front fender apron and hood sill hold-down bolt	10	117122
Nut	10	102624
Plain washer	10	103354
Lockwasher	10	115547

## REAR FENDER

Rear fender, right (Coupe) (L. H. D.)	1	93777
Rear fender, right (De Luxe Coupe) (L. H. D.)	1	93540
Rear fender, left (Coupes) (L. H. D.)	1	93541
Rear fender, right (Coupes) (R. H. D.)	1	93538
Rear fender, left (Coupe) (R. H. D.)	1	93976
Rear fender, left (De Luxe Coupe) (R. H. D.)	1	93539
Rear fender, right (Two-door Sedan and Four-door Sedan) (L. H. D.)	1	93521
Rear fender, left (Two-door Sedan and Four-door Sedan) (L. H. D.)	1	93522
Rear fender, right (Two-door Sedan and Four-door Sedan) (R. H. D.)	1	93519
Rear fender, left (Two-door Sedan and Four-door Sedan) (R. H. D.)	1	93520
Rear fender, right (Touring) (L. H. D.)	1	92878
Rear fender, left (Touring) (L. H. D.)	1	92879
Rear fender, right (Touring) (R. H. D.)	1	93536
Rear fender, left (Touring) (R. H. D.)	1	93537
Rear fender, right (Roadster) (L. H. D.)	1	92882
Rear fender, left (Roadster) (L. H. D.)	1	92883
Rear fender, right (Roadster) (R. H. D.)	1	93534



## FENDERS, RUNNING BOARDS AND DUST SHIELDS (Continued)

REAR FENDER (Continued)		
PART NAME	Per Car	Part Number
Rear fender, left (Roadster) (R. H. D.)	1	93535
Screw (fender to body)	16	106325
Screw lockwasher	16	103320
Screw plain washer	16	82488
Screw (fender to running board)	6	118568
Screw nut	6	115763
Rear fender to body welt	as reqd.	81025

## RUNNING BOARD

Running board assembly, right	1	43186
Running board assembly, left	1	43187
Running board mat, right	1	43197
Running board mat, left	1	43198
Running board inside moulding, right	1	43195
Running board inside moulding, left	1	43196
Running board outside moulding, right	1	43856
Running board outside moulding, left	1	43857
Running board outside moulding clamping strip	2	43194
Running board front end moulding, right	1	79118
Running board front end moulding, left	1	79119
Running board rear end moulding, right	1	79120
Running board rear end moulding, left	1	79121
Running board moulding rivet	20	111863
Running board fastening bolt	8	79671
Nut	8	114771
Plain washer	8	103340
Lockwasher	8	115548
Running board bracket spacer and fastening bolt assembly	8	74506
Running board to fender liner (front)	2	79022
Running board to fender liner (rear)	2	79572
Running board brackets (see Frame Group)		

## SPLASH GUARD (DUST SHIELD)

Running board splash guard, right	1	43181
Running board splash guard, left	1	43182
Running board splash guard to frame bolt and nut	4	101291
Plain washer	4	11043
Lockwasher	8	114604
Running board splash guard to running board bolt	10	111024
Nut	10	114983
Plain washer	10	103340
Lockwasher	10	103320
Running board splash guard liner	2	43219
Running board splash guard to running board liner	2	43180

## FENDERS, RUNNING BOARDS AND DUST SHIELDS (Continued)

RADIATOR DUST SHIELD		
PART NAME	Per Car	Part Number
Radiator dust shield assembly	1	43284
Radiator dust shield side bolt	2	37842
Nut	2	105616
Plain washer	2	106262
Lockwasher	2	115548
Radiator dust shield felt washer	4	35306
Rivet	4	104449
Radiator dust shield to frame bracket	2	56743
Bolt	2	106279
Bolt nut	2	103025
Bolt lockwasher	2	115548

## ENGINE DUST PAN

Engine dust pan assembly, right	1	43297
Engine dust pan assembly, left	1	43298
Engine dust pan support (front)	1	43402
Engine dust pan to support bolt and nut	4	101292
Plain washer	4	103339
Lockwasher	4	115547
Engine dust pan to flywheel housing bolt	2	106324
Plain washer	2	103340
Lockwasher	2	115548
Engine dust pan to frame bolt and nut	8	107632
Plain washer	8	103339
Lockwasher	16	115547

## FRAME

## FRAME ASSEMBLY

PART NAME	Per Car	Part Number
Frame and brackets assembly (L. H. D.)	1	44127
Frame and brackets assembly (R. H. D.)	1	43244

## FRAME MEMBERS

Frame side member, right (L. H. D.)	1	43144
Frame side member, left (L. H. D.)	1	43145
Frame side member, right (R. H. D.)	1	44660
Frame side member, left (R. H. D.)	1	44662
Frame engine front support	1	43212
Frame engine front support gusset, right	1	43213
Frame engine front support gusset, left	1	43214
Frame front intermediate cross member	1	43146
Frame rear intermediate cross member	1	43149
Frame rear cross member	1	43226
Tire carrier to rear cross member clinch nut	2	43436
Tire carrier to rear cross member clinch nut	6	43435

## ENGINE REAR SUPPORT BRACKET (SEE ENGINE GROUP)

## SPRING HANGERS

Front spring front hanger, right	1	43160
Front spring front hanger, left	1	43161
Front spring rear hanger and shackle pin assembly	2	43162
Front spring rear hanger shackle pin	2	43102
Rear spring front hanger assembly	2	41396
Rear spring rear hanger and shackle pin assembly	1	43164
Rear spring rear hanger and shackle pin assembly	1	43165
Rear spring rear hanger shackle pin	2	43102

## RUNNING BOARD BRACKET

Running board bracket (front)	2	51302
Running board bracket (rear)	2	51258
Running board bracket rivet	16	104098

## BATTERY SUPPORT

Battery support assembly	1	43177
Rivet (to frame)	4	104098
Battery support clamp bolt	1	9880
Nut	1	102634
Lockwasher	1	108579
Battery support brace	1	42287
Bolt (to frame)	1	100013
Bolt nut	1	103025
Bolt lockwasher	1	103320

## BODY BRACKET

Rear body bracket	2	74656
-------------------	---	-------

## FRAME (Continued)

## BUMPERS

PART NAME	Per Car	Part Number
Front bumper assembly	1	43183
Attaching screw	2	43966
Attaching screw lockwasher	2	116121
Rear bumper assembly, right	1	43184
Rear bumper assembly, left	1	43185
Rear bumper assembly (Fulgard) (for use with side tire carrier)	1	43407
Attaching screw (inner)	4	43269
Attaching screw (inner lockwasher)	2	115093
Attaching screw (outer) (except Fulgard bumper)	2	43966
Attaching screw (outer lockwasher)	2	116121
Attaching screw (outer) (for use with Fulgard bumper)	2	44103

## FUEL SYSTEM

## GASOLINE TANK

PART NAME	Per Car	Part Number
Gasoline tank assembly.....	1	78804
Gasoline tank drain plug.....	1	103865
Gasoline tank filler cap.....	1	41048
Gasoline tank filler cap gasket (leather).....	1	41049

## GASOLINE GAUGE

Gasoline gauge.....	1	42665
Gasoline gauge float and dial assembly.....	1	42666
Gasoline gauge glass.....	1	42667
Gasoline gauge glass gasket (upper).....	1	79513
Gasoline gauge gasket (lower).....	1	42678
Gasoline gauge unit retainer.....	1	42677
Screw.....	5	101023
Gasoline gauge cap.....	1	42679

## GASOLINE TANK SUPPORT

Gasoline tank support.....	2	78445
Gasoline tank support strap.....	2	78450
Nut.....	4	103026
Lockwasher.....	2	115549

## CARBURETOR

Carburetor assembly (Carter RJO8-112S) (domestic cars).....	1	42783*
Carburetor assembly (Carter DRJO8-114S) (L. H. D.) (export cars).....	1	42813*
Carburetor assembly (Carter DRJO8-113S) (R. H. D.).....	1	42974
Carburetor to manifold stud.....	2	42451
Nut.....	2	103025
Carburetor to manifold gasket.....	1	5131
Carburetor throttle spring.....	1	5588
Carburetor throttle spring clip.....	1	9013
Air cleaner (domestic cars).....	1	42654
Air cleaner (export cars).....	1	42226

## CARBURETOR CHOKE CONTROL

Choke button and wire assembly.....	1	42687
Choke guide and tube assembly.....	1	42688
Choke guide mounting nut.....	1	70779
Choke guide mounting nut lockwasher.....	1	110730

## VACUUM TANK

Vacuum tank assembly.....	1	43280
Bolt and nut (to dash).....	4	100426
Bolt lockwasher.....	4	114604

\*Domestic and overseas service by Carter Carburetor Corp., St. Louis, Mo., U. S. A.

## FUEL SYSTEM (Continued)

## VACUUM TANK (Continued)

PART NAME	Per Car	Part Number
Vacuum tank bracket.....	2	56939
Clamp bolt.....	2	113961
Clamp bolt nut.....	2	114378
Clamp bolt lockwasher.....	2	103319
Vacuum tank elbow (to gasoline tank).....	1	78723
Vacuum tank elbow (to oil pump).....	1	42204
Vacuum tank operating chamber assembly.....	1	78719
Vacuum tank reservoir chamber assembly.....	1	42201
Vacuum tank reservoir tank spring.....	2	43259
Vacuum tank reservoir chamber cover assembly.....	1	42203
Vacuum tank partition plate assembly.....	1	78717
Screw.....	5	113625
Vacuum tank partition plate gasket.....	1	78718
Vacuum tank drain valve.....	1	33931
Vacuum tank shut-off cock.....	1	79852

## GASOLINE TUBES

Gasoline tank to vacuum tank tube assembly.....	1	43275
Elbow (on gasoline tank).....	1	115569
Nut.....	2	115681
Sleeve.....	2	114628
Vacuum tank to carburetor tube assembly.....	1	43282
Nut (at carburetor).....	1	42544
Nut.....	1	115681
Sleeve (at carburetor).....	1	42543
Sleeve.....	1	114628
Vacuum tank to oil pump tube assembly.....	1	41527
Nut.....	2	10117
Sleeve.....	2	10118
Clip (on dash).....	1	50178

## THROTTLE CONTROL

Throttle control link.....	1	37947
Bolt.....	1	100274
Bolt nut.....	1	109084
Bell crank.....	1	35969
Bell crank screw (L. H. D.).....	1	30550
Bell crank rod (L. H. D.).....	1	41680
Cotter pin.....	1	103361
Bell crank rod spring clip.....	1	37424
Bell crank rod spring (L. H. D.).....	1	5588
Bell crank rod spring clip (L. H. D.) (on rear water inlet screw).....	1	9013
Throttle control spring (R. H. D.).....	1	79945
Clip.....	1	42290

## FUEL SYSTEM (Continued)

## THROTTLE CONTROL (Continued)

PART NAME	Per Car	Part Number
Throttle control rod (link to carburetor) (L. H. D.)	1	42282
Ball joint	1	115371
Ball joint nut	1	103088
Ball joint lockwasher	1	114604
Throttle control rod (steering gear to carburetor) (R. H. D.)	1	43028
Spring	1	79152
Washer	1	106260
Cotter pin	1	103361
Swivel	1	43029
Swivel washer	1	106261
Swivel cotter pin	1	103361
Adjusting clamp	1	43030
Adjusting clamp bolt and nut	1	101280
Adjusting clamp bolt nut lockwasher	1	114603
Throttle control rod (steering gear to bell crank)	1	41677
Ball joint	1	115371
Ball joint nut	1	103088
Ball joint lockwasher	1	114604
Cotter pin	1	103361

## ACCELERATOR PEDAL

Accelerator pedal (L. H. D.)	1	41553
Accelerator pedal button (L. H. D.)	1	37954
Accelerator pedal rod (R. H. D.)	1	43428
Button	1	42462
Cotter pin	1	103361
Accelerator pedal bracket	2	37958
Accelerator pedal bracket plate	2	37955
Bolt	3	107632
Bolt lockwasher	4	115547
Accelerator rod floor board bushing (R. H. D.)	1	44244
Nut	1	44245
Lockwasher	1	114608

## ACCELERATOR FOOT REST

Accelerator foot rest	1	31282
Screw	3	105857

## HOOD

PART NAME	Per Car	Part Number
Hood assembly (specify color and stripe, also give car serial number to insure correct finish)	1	46566
Hood corner protector	4	80871
Hood upper hinge rod spacer	1	47361

## HOOD HANDLE

Hood handle	2	93405
Rivet	4	121646
Rivet washer	4	104564

## HOOD LOCK

Hood lock	4	43292
Rivet	8	120184
Hood lock catch	4	79850
Rivet	8	121646
Rivet washer	8	104564

## HOOD SILLS

Hood sills (see Front Fender Section)

## LAMPS

## HEAD LAMP

PART NAME	Per Car	Part Number
Head lamp assembly	2	42670
Head lamp mounting stud cup washer	2	56830
Head lamp mounting stud nut	2	102637
Lockwasher	2	108573
Head lamp bulb (large)	2	115309
Head lamp bulb (small)	2	115428

## HEAD LAMP TIE ROD

Head lamp tie rod	1	78355
Tie rod bolt	4	121526
Tie rod bolt nut	4	115573
Tie rod bolt lockwasher	4	118930
Tie rod to fender pad	2	78919

## INSTRUMENT PANEL LAMP

Instrument lamp assembly	1	79510
Instrument lamp housing (see Ammeter Section—Electrical System Group)		
Instrument lamp bulb	1	115428
Instrument lamp wire terminal	1	114038
Sleeve	1	50228

## DOME LAMPS (TWO-DOOR SEDAN AND FOUR-DOOR SEDAN)

Dome lamp and switch assembly	1	
Bulb	1	119294

## TAIL AND SIGNAL LAMP

Tail and signal lamp assembly	1	43731
Tail and signal lamp stud nut	2	120362
Lockwasher	2	120380
Tail and signal lamp bulb	1	119314
Tail and signal lamp door assembly	1	42401
Locking screw	2	42405

## TAIL AND SIGNAL LAMP BRACKET

Tail and signal lamp bracket	1	79036
Bolt	3	79040
Bolt nut	3	105604
Bolt lockwasher	3	114604
Shim	1	79963

## LICENSE BRACKET

Front license plate bracket	2	A10076
Front license bolt and nut	2	101292
Bolt lockwasher	2	114604
Rear license bracket	1	79037

## OILING SYSTEM

## OIL PAN

PART NAME	Per Car	Part Number
Oil pan assembly	1	41074
Fastening screw (long)	1	106326
Fastening screw (short)	13	106324
Fastening screw lockwasher	14	108579
Oil pan gasket	1	31059
Oil pan drain plug and suction screen assembly	1	42254
Oil pan drain plug gasket	1	31334

## OIL LEVEL INDICATOR

Oil level indicator	1	41086
---------------------	---	-------

## OIL LINES

Oil distributor tube (to crankshaft bearings)	2	31039
Oil distributor tube nut	4	152119
Oil suction tube assembly	1	A841
Union nut	1	10124
Oil pressure tube assembly	1	A770
Union nut	1	10124
Nut	1	114965
Oil suction and pressure tube block	1	31042
Oil suction and pressure tube block gasket	1	40094
Oil pressure gauge tube assembly (to gauge)	1	38399
Union nut	2	10117
Sleeve	2	10118
Clip (to motor)	1	31037
Camshaft center bearing oil tube (see Camshaft Section—Engine Group)		

## OIL PUMP

Oil pump assembly	1	41966
Fastening screw	2	100126
Fastening screw lockwasher	2	108579
Oil pump to cylinder block gasket	1	31451
Oil pump cover	1	31452
Screw	3	100660
Screw washer	3	11239
Oil pump cover gasket	1	41968
Oil pump blade	1	41965
Oil pump blade spring	2	37561
Oil pump blade drive shaft	1	41969
Oil pump driven gear	1	31045
Key	1	106749
Nut	1	103056
Oil pump driven gear washer	1	31066
Oil pump suction connection	1	35757
Oil pump pressure tee	1	42887
Oil pump gauge tee	1	42886
Oil pump priming plug	1	103877

## OILING SYSTEM (Continued)

## OIL PRESSURE RELIEF VALVE

PART NAME	Per Car	Part Number
Oil distributor body and tube assembly.....	1	A842
Screw.....	2	106324
Screw lockwasher.....	2	103320
Oil distributor body gasket.....	1	31057
Oil relief valve plunger.....	1	33119
Oil relief valve spring.....	1	33118
Oil relief valve spring plug.....	1	33120
Cotter pin.....	1	108640

## OIL PRESSURE GAUGE

Oil pressure gauge assembly (see Ammeter Section—Electrical System Group)

## PROPELLER SHAFT AND UNIVERSAL JOINT

## PROPELLER SHAFT

PART NAME	Per Car	Part Number
Propeller shaft assembly.....	1	42891
Propeller shaft spider bolt (rear).....	3	41263
Propeller shaft spider bolt (rear).....	6	42329
Transmission mainshaft spider bolt.....	3	41265
Spider bolt nut.....	12	41377
Plain washer.....	12	106264
Cotter pin.....	12	103374

## UNIVERSAL JOINT

Universal joint spider (on mainshaft) (see Transmission Main Shaft Section)

Universal joint spider (on drive pinion) (see Rear Axle Drive Pinion Section)

Universal joint disc.....	5	41262
Universal joint disc buckle plate.....	42	9307

12  
52  
108

## SPEEDOMETER

## SPEEDOMETER HEAD

PART NAME	Per Car	Part Number
Speedometer assembly (mile register).....	1	78906*
Speedometer assembly (kilometer register).....	1	78907*
Fastening bolt.....	3	110382
Fastening bolt nut.....	3	114769
Lockwasher.....	3	115545

## SPEEDOMETER GEARS

Speedometer drive gear.....	1	42163
Key.....	1	106749
Speedometer drive pinion (4.3 to 1 ratio).....	1	42326
Speedometer drive pinion sleeve.....	1	56751
Speedometer drive pinion bushing.....	1	56747

## FLEXIBLE SHAFT

Flexible shaft assembly.....	1	79541
Grommet.....	1	76205
Clip.....	1	77955

\*Domestic and overseas service by the North East Service, Inc., Rochester, N. Y., U. S. A.

## SPRINGS

## FRONT SPRING

PART NAME	Per Car	Part Number
Front spring assembly.....	2	43606
Front spring bushing.....	2	42701

## REAR SPRING

Rear spring assembly (Touring and DeLuxe Coupe).....	2	43609
Rear spring assembly (Two-door Sedan and Four-door Sedan).....	2	43607
Rear spring assembly (Roadster and Coupe).....	2	43608
Rear spring front bushing.....	2	42702

## SPRING BOLTS

Front spring center bolt.....	2	41489
Nut.....	2	103025
Front spring front bolt.....	2	41486
Nut.....	2	114497
Plain washer.....	2	41490
Lockwasher.....	2	112724
Oiler.....	2	115076
Front spring shackle bolt.....	2	43204
Nut.....	2	43207
Lockwasher.....	2	43632
Oiler (upper).....	2	115076
Oiler (lower).....	2	52347
Rear spring center bolt (Touring and DeLuxe Coupe).....	2	41489
Rear spring center bolt (Two-door Sedan and Four-door Sedan).....	2	71305
Rear spring center bolt (Roadster and Coupe).....	2	41488
Nut.....	2	103025
Rear spring front bolt.....	2	41487
Nut.....	2	114498
Lockwasher.....	2	103334
Oiler.....	2	115078
Rear spring shackle bolt.....	2	43201
Nut.....	2	43207
Lockwasher.....	2	43632
Oiler.....	4	115076

## SPRING SHACKLE

Front spring shackle (inner).....	2	43203
Front spring shackle (outer).....	2	43202
Front spring shackle pin.....	2	43102
Front spring shackle spring.....	2	43205
Rear spring shackle (inner).....	2	43200
Rear spring shackle (outer).....	2	43199
Rear spring shackle pin.....	2	43102
Rear spring shackle spring.....	4	43205

## SPRINGS (Continued)

## SPRING AXLE CLIPS

PART NAME	Per Car	Part Number
Front spring clip	4	43266
Front spring clip (front) (cars equipped with shock absorbers)	2	43265
Front spring clip nut	8	1424
Lockwasher	8	118974
Front spring axle bumper (rubber)	2	43281
Rear spring clip	4	43268
Rear spring clip nut	8	1424
Lockwasher	8	118974
Rear spring clip plate, right	1	43270
Rear spring clip plate, left	1	43271

## SPRING COVERS (Not Standard Equipment)

Spring covers (service package) (Touring and DeLuxe Coupe)	1	42532
Spring covers (service package) (Roadster and Coupe)	1	42534
Spring covers (service package) (Two-door Sedan and Four-door Sedan)	1	42533
Front spring front cover	2	42535
Front spring rear cover	2	42536
Rear spring front cover (Touring and DeLuxe Coupe)	2	42537
Rear spring rear cover (Touring and DeLuxe Coupe)	2	42538
Rear spring front cover (Roadster and Coupe)	2	42541
Rear Spring rear cover (Roadster and Coupe)	2	42542
Rear spring front cover (Two-door Sedan and Four-door Sedan)	2	42539
Rear spring rear cover (Two-door Sedan and Four-door Sedan)	2	42540

## STEERING GEAR

## HOUSING

PART NAME	Per Car	Part Number
Housing and bushing assembly (L. H. D.)	1	42821
Housing and bushing assembly (R. H. D.)	1	42822
Clamp bolt	1	100029
Clamp bolt nut	1	103026
Clamp bolt lockwasher	1	103321
Housing bushing	1	42825
Housing oil seal	1	42828
Housing oil seal washer	1	42829
Housing nipple	1	115076

## HOUSING BRACKET

Housing bracket and bushing assembly (L. H. D.)	1	42989
Housing bracket and bushing assembly (R. H. D.)	1	42850
Housing bracket stud	1	42826
Nut	1	103026
Lockwasher	1	103321
Housing bracket to frame bolt	4	77536
Nut	4	103026
Plain washer	4	76818
Lockwasher	4	103321
Housing bracket bushing	2	42853
Housing bracket gasket	1	42827

## WORM

Worm (L. H. D.)	1	42834
Worm (R. H. D.)	1	42835
Worm key	1	42837
Worm thrust bearing	2	42836
Worm adjusting nut	1	42830
Worm adjusting nut spacer and bushing assembly	1	42831
Worm adjusting nut spacer bushing	1	42833
Worm wheel (L. H. D.)	1	42838
Worm wheel (R. H. D.)	1	42839
Worm wheel adjusting screw	1	42840
Nut	1	114495
Nut lockwasher	1	110405
Worm wheel thrust screw	1	42841
Nut	1	42843
Washer	1	42842
Lockwasher	1	103334

## MAIN TUBE

Main tube (L. H. D.)	1	43493
Main tube (R. H. D.)	1	43811
Main tube silencer (upper)	1	42859
Main tube silencer (lower)	1	42860



## STEERING GEAR (Continued)

## COLUMN JACKET

PART NAME	Per Car	Part Number
Column jacket and bushing assembly (L. H. D.)	1	43497
Column jacket and bushing assembly (R. H. D.)	1	43803
Column jacket bushing	1	42856

## STATIONARY TUBE

Stationary tube (L. H. D.) (domestic cars)	1	43494
Stationary tube (L. H. D.) (export cars)	1	43495
Stationary tube (R. H. D.)	1	43809
Stationary tube clamp	1	42844
Stationary tube clamp plate	1	42846
Stationary tube clamp plate gasket	1	42847
Stationary tube clamp bolt	1	100003
Nut	1	103024
Stationary tube clamp screw	2	121533
Lockwasher	2	103319

## LIGHT CONTROL

Light control tube (L. H. D.)	1	43499
Light control tube (R. H. D.)	1	43807
Lighting switch	1	43719
Lighting switch bracket	1	42668
Lighting switch drip shield (R. H. D.)	1	44123
Clamp bolt and nut	1	101280
Clamp bolt nut lockwasher	1	114603

## THROTTLE CONTROL

Throttle control tube assembly (L. H. D.)	1	43498
Throttle control tube assembly (R. H. D.)	1	43805
Throttle control lower lever	1	44577
Clamp bolt	1	106276
Clamp bolt nut	1	103024

## UPPER CONTROL

Upper control friction plate (upper)	1	42872
Upper control friction plate (lower)	1	42873
Upper control friction plate spring	1	42874
Upper control cover	1	42870
Upper control cover screw	2	110682
Upper control cover screw spacer	2	42871
Upper control cover screw lockwasher	2	114614

## HORN BUTTON

Horn button	1	42875
Horn button spring	1	42876

## STEERING WHEEL

Steering wheel (domestic cars)	1	42992
Steering wheel (export cars)	1	42180
Steering wheel nut	1	42877
Steering wheel key	1	42837

## STEERING GEAR (Continued)

## STEERING GEAR ARM

Steering gear arm (see Front Axle Group)

## STEERING POST BRACKET

PART NAME	Per Car	Part Number
Steering post bracket (open cars)	1	92726
Steering post bracket (closed cars)	1	92434
Bolt (to support)	3	100122
Bolt nut	2	102634
Bolt lockwasher	2	103320
Steering post bracket cap	1	83587
Screw (to bracket)	2	117293
Screw lockwasher	2	103320
Steering post bracket support (L. H. D.) (open cars)	1	46741
Steering post bracket support (R. H. D.) (open cars)	1	46740
Steering post bracket support (L. H. D.) (closed cars)	1	46598
Steering post bracket support (R. H. D.) (closed cars)	1	46597
Rivet (support to bracket)	4	102670
Screw nut	3	102634
Lockwasher	3	103320
Steering post bracket insulator	2	83603

**TOOLS**  
**TOOLS**

PART NAME	Per Car	Part Number
Starting crank assembly.....	1	A575
Starting crank pin.....	1	10116
Hub cap wrench.....	1	42318
Rim wrench.....	1	71794
Tire pump.....	1	12062
Auto jack.....	1	41774
Auto jack handle.....	1	41775
Tool bag with tools.....	1	41606
Wrench No. 1.....	1	41593
Wrench No. 2.....	1	41594
Wrench No. 4.....	1	30773
Screwdriver (large).....	1	41597
Hammer.....	1	51826
Pliers.....	1	51827
Push rod adjusting screw nut wrench.....	1	12044
Zerk oil gun.....	1	115305
Wheel cylinder bleeder hose assembly.....	1	51554
Wheel cylinder bleeder hose connection gasket.....	1	51564

**TRANSMISSION**  
**TRANSMISSION CASE**

PART NAME	Per Car	Part Number
Transmission case.....	1	42948
Transmission case filler plug.....	1	103868
Transmission case drain plug.....	1	103868
Transmission brake support (see Transmission Brake Group)		

**MAINSHAFT**

Mainshaft.....	1	42949
Mainshaft spider.....	1	41134
Mainshaft nut.....	1	33208
Cotter pin.....	1	103387
Mainshaft nut washer.....	1	50652
Mainshaft pilot bushing.....	1	42950
Mainshaft rear bearing.....	1	41254
Mainshaft rear bearing retainer snap ring.....	1	41128
Mainshaft rear bearing retainer assembly.....	1	41267
Fastening screw.....	3	100122
Fastening screw lockwasher.....	3	115548
Mainshaft rear bearing retainer gasket.....	1	41130
Mainshaft rear bearing oil washer assembly.....	1	41273

**SLIDING GEARS**

Sliding gear (first and reverse).....	1	42961
Sliding gear (direct and second).....	1	42962

**MAIN DRIVE PINION**

Drive pinion and pilot bushing assembly (clutch or pocket gear).....	1	42951
Drive pinion snap ring.....	1	42960
Drive pinion bearing.....	1	42953
Drive pinion bearing snap ring.....	1	42959
Drive pinion bearing retainer.....	1	42954
Screw.....	3	42956
Screw lockwasher.....	3	115548
Drive pinion bearing retainer gasket.....	1	42955
Drive pinion bearing retaining washer.....	1	42958
Drive pinion bearing oil fling.....	1	42957
Drive pinion pilot bushing (see Crankshaft Section—Engine Group)		

**COUNTERSHAFT**

Countershaft.....	1	41142
Countershaft and idler lock plate.....	1	41180
Screw.....	1	42491
Screw lockwasher.....	1	115548
Countershaft gear assembly.....	1	42963
Countershaft gear bushing.....	2	41144

## TRANSMISSION (Continued)

PART NAME	Per Car	Part Number
<b>REVERSE IDLER GEAR</b>		
Reverse idler gear assembly	1	42965
Reverse idler gear bushing	1	41147
Reverse idler gear shaft	1	41145
<b>GEAR SHIFT HOUSING</b>		
Gear shift housing	1	42968
Screw	4	42491
Screw lockwasher	4	103320
Gear shift housing gasket	1	42970
<b>GEAR SHIFT SHAFT</b>		
Gear shift shaft (direct and second)	1	41169
Gear shift shaft (low and reverse)	1	41170
Gear shift shaft lock plate	1	41172
Gear shift shaft selector ball	2	104920
Gear shift shaft selector ball spring	2	41179
Gear shift shaft interlock ball	2	104919
Gear shift interlock shaft	1	42172
<b>GEAR SHIFT FORK</b>		
Gear shift fork	2	41168
<b>GEAR SHIFT LEVER</b>		
Gear shift lever	1	43074
Gear shift lever spring	1	33253
Gear shift lever locating pin	1	33238
Gear shift lever knob	1	42971
Gear shift lever ball pin	1	56783

## WHEELS

PART NAME	Per Car	Part Number
<b>WOOD WHEELS</b>		
Front wheel assembly (specify color of wheel and stripe, also give car serial number to insure correct finish)	2	42923
Rear wheel assembly (specify color of wheel and stripe, also give car serial number to insure correct finish)	2	42930
<b>WIRE AND DISC WHEELS (Not Standard Equipment)</b>		
Wire wheel assembly (does not include tire side ring)	5	43995
Wire wheel spoke, inner	100	43996
Wire wheel spoke, outer	100	43997
Wire wheel tire side ring	5	44100
Disc wheel assembly (does not include tire side ring)	5	41734
Disc wheel tire locking ring	5	41743
<b>WOOD WHEEL HUBS</b>		
Front wheel hub and bearing cup assembly	2	40487
Front wheel hub dust washer assembly	2	41403
Front wheel hub flange	2	41025
Rear wheel hub	2	40499
Wheel hub bolt	32	114902
Wheel hub bolt nut	32	51509
<b>WIRE WHEEL HUBS</b>		
Front wheel hub and brake drum assembly	2	44002
Rear wheel hub and brake drum assembly	2	44004
Wheel hub stud	20	44006
Wheel hub stud nut	20	44007
<b>DISC WHEEL HUBS</b>		
Front wheel hub and brake drum assembly, right	1	43042
Front wheel hub and brake drum assembly, left	1	43043
Rear wheel hub and brake drum assembly, right	1	43044
Rear wheel hub and brake drum assembly, left	1	43045
Wheel hub stud, right	8	70946
Wheel hub stud, left	8	70947
Wheel hub stud nut, right	8	70948
Wheel hub stud nut, left	8	70949
<b>BRAKE DRUMS</b>		
Front wood wheel brake drum	2	42927
Rear wood wheel brake drum	2	42934
Wire wheel brake drum	4	44009
Bolt	12	44010
Bolt nut	12	44101
Disc wheel brake drum	4	43041
Rivet	16	41742

## WHEELS (Continued)

## HUB CAPS

PART NAME	Per Car	Part Number
Wheel hub cap (wood and disc wheels)	4	44816
Wire wheel hub shell cap	5	43999
Wire wheel front hub grease cap	2	20853

## FRONT WHEEL BEARINGS

Front wheel inner bearing cone and rollers	2	40420
Front wheel inner bearing cup	2	40421
Front wheel outer bearing cone and rollers	2	40423
Front wheel outer bearing cup	2	40424
Front wheel bearing nut (steering knuckle nut)	2	33208
Front wheel bearing thrust washer	2	38422
Front wheel bearing nut cotter pin	2	103386

## DEMOUNTABLE RIM (Wood Wheels)

Demountable rim	5	43988
Rim lock pin	5	40496
Rim clamp	16	40502
Rim clamp bolt	16	40503
Rim clamp bolt nut	16	41448

## SPARE TIRE CARRIER (Wood Wheels) (Rear Mounting)

Tire carrier assembly (does not include demountable rim) (Touring, Four-door Sedan and Two-door Sedan)	1	43415
Tire carrier assembly (does not include demountable rim) (Roadster, Coupe and DeLuxe Coupe)	1	43416
Screw (to frame) (six on Roadster and Coupes)	8	111046
Screw lockwasher	8	118930
Tire carrier bracket, right (Touring, Four-door Sedan and Two-door Sedan)	1	43422
Tire carrier bracket, left (Touring, Four-door Sedan and Two-door Sedan)	1	43423
Tire carrier bracket, right (Roadster and Coupes)	1	43424
Tire carrier bracket, left (Roadster and Coupes)	1	43425
Tire carrier brace (Roadster and Coupes)	1	43420
Nut (to body bracket)	1	106638
Nut lockwasher	1	103323
Bolt (to tire carrier)	1	111048
Bolt nut	1	114984
Bolt nut lockwasher	1	115549
Tire carrier rim clamp	1	78978
Tire carrier rim clamp stud	1	53726
Tire carrier rim clamp stud nut	1	72520
Tire carrier rim lock, housing and keys assembly (not standard equipment)	1	41894
Housing	1	41893
Housing retainer nut	1	41933
Lock cylinder with keys	1	72946
Key (specify key serial number)	2	70855

## WHEELS (Continued)

## SPARE WIRE AND DISC WHEEL CARRIER (Rear Mounting)

PART NAME	Per Car	Part Number
Spare wheel carrier bracket and plate assembly (Roadster and Coupes)	1	44032
Spare wheel carrier bracket and plate assembly (Touring and Sedans)	1	44031
Spare wheel carrier bracket, right (Roadster and Coupes)	1	44036
Spare wheel carrier bracket, left (Roadster and Coupes)	1	44037
Spare wheel carrier bracket, right (Touring and Sedans)	1	44034
Spare wheel carrier bracket, left (Touring and Sedans)	1	44035
Screw (to frame) (with bumper)	2	111052
Screw (to frame)	6	111047
Screw lockwasher	8	115549
Spare wheel carrier plate	1	44033
Stud, short	1	44039
Stud, long	4	44038
Stud nut	5	103028
Stud nut lockwasher	5	103323
Stud wheel nut	4	44007
Spare wheel carrier brace (Roadster and Coupes)	1	44040
Nut (to body bracket)	1	106638
Nut lockwasher	1	103323
Nut (to plate)	1	103028
Nut lockwasher	1	103323
Check nut (to plate)	1	103056
Spare wire wheel lock and key assembly	1	44091
Key (specify key serial number)	2	70855

## SIDE TIRE CARRIER (Not Standard Equipment) (Wood, Wire and Disc Wheels)

Side tire carrier support bracket, right (open cars)	1	94006
Side tire carrier support bracket, left (open cars)	1	94007
Bolt and nut	4	101335
Bolt nut lockwasher	4	101944
Screw	4	106497
Side tire carrier fender brace, right	1	43217
Side tire carrier fender brace, left	1	43216
Bolt	2	100025
Bolt nut	2	103026
Bolt nut lockwasher	2	103321
Bolt (brace to fender)	1	79595
Bolt nut	1	105605
Bolt nut lockwasher	1	114605
Side tire carrier brace (closed cars)	1	44576
Side tire carrier brace (open cars)	1	44575
Side tire carrier brace clamp	1	79692
Bolt	1	107871
Bolt nut	1	107636
Bolt nut lockwasher	1	103454
Side tire carrier brace nut	2	102635
Lockwasher	1	103321

## WHEELS (Continued)

SIDE TIRE CARRIER (Not Standard Equipment) (Wood, Wire and Disc Wheels)  
(Continued)

PART NAME	Per Car	Part Number
Side tire carrier clamp	1	79686
Side tire carrier clamp rod	1	79687
Nut	1	103028
Nut lockwasher	1	103323
Check nut	1	78790
Check nut washer	1	78791
Side tire carrier clamp wing nut	1	79688
Side tire carrier clamp rod reinforcement	1	43623
Side tire carrier lock bar	1	43273
Side tire carrier lock housing	1	43272
Pad	1	79828
Screw	4	43622
Screw lockwasher	4	115547
Screw	1	100157
Side tire carrier lock cylinder and key assembly	1	44514
Key (specify key serial number)	2	76575

## SPARE TIRE COVERS (Not Standard Equipment)

Tire cover (drum type) (wood wheel—rear mounting)	1	47324
Tire cover (open type) (wood wheel—side mounting and wire and disc wheel—side or rear mounting)	1	45918

## WIRING

## STARTING CABLES

PART NAME	Per Car	Part Number
Starting motor to starter switch cable assembly	1	74961
Terminal	2	114062
Battery to starter switch cable assembly	1	74959
Terminal (starter switch end)	1	114062
Terminal assembly (battery end)	1	50170
Terminal bolt and nut (battery end)	1	50175
Clip	1	52395
Battery ground connection assembly	1	38041
Bolt and nut (battery end)	1	50175
Bolt (to frame)	1	100013
Bolt nut	1	103025
Bolt lockwasher	1	108579
Magneto to switch cable assembly	1	42378
Terminal	1	114038
Sleeve	1	50228
Magneto switch to ground cable assembly	1	42128
Terminal	2	114038
Sleeve	2	50228

## GROUND STRIP

Engine ground strip	1	43504
---------------------	---	-------

## IGNITION CABLES

Ignition switch lock housing, cables and grommets assembly	1	42676
Distributor to No. 1 spark plug cable	1	43351
Distributor to No. 2 spark plug cable	1	43353
Distributor to No. 3 spark plug cable	1	43355
Distributor to No. 4 spark plug cable	1	43357
Terminal (spark plug end)	4	74272
Terminal (distributor end)	4	71111
Nipple	4	35712
Magneto to No. 1 spark plug cable	1	42380
Magneto to No. 2 spark plug cable	1	42382
Magneto to No. 3 spark plug cable	1	42398
Magneto to No. 4 spark plug cable	1	42384
Terminal (spark plug end)	4	72757
Terminal nipple	4	72756
Distributor to coil secondary cable	1	43359
Terminal	2	71111
Nipple	2	35712
Ignition cable support bracket	1	42390
Ignition cable support bracket (4 required with magneto)	3	40437
Ignition cable support bracket grommet (No. 1)	1	42388
Ignition cable support bracket grommet (Nos. 2 and 3)	2	40439
Ignition cable support bracket grommet (No. 4)	1	117965
Distributor to spark plug cable ring	1	40457
Magneto cable grommet	1	40438
Magneto cable grommet	1	75751

## WIRING (Continued)

## IGNITION CABLES (Continued)

PART NAME	Per Car	Part Number
Magneto cable support bracket	1	42400
Magneto wire support (on hood sill)	1	30940
Dash to instrument board cable housing	1	76136

## WIRES

Instrument board to chassis wiring assembly (L. H. D.)	1	43361
Instrument board to chassis wiring assembly (R. H. D.)	1	43362
Mounting clip, small	1	43378
Mounting clip, large	1	43377
Lighting switch to horn and signal lamp switch cables assembly (L. H. D.)	1	43365
Lighting switch to horn and signal lamp switch cables assembly (R. H. D.)	1	43507
Terminal (lighting switch to horn and signal lamp)	1	114061
Terminal sleeve	1	50229
Terminal (lighting switch to signal lamp switch)	1	76547
Terminal sleeve	1	50228
Terminal (lighting switch to horn)	1	114038
Lighting switch to tail lamp cable assembly	1	43372
Terminal	1	114034
Head lamp cables and housing assembly	1	43379
Terminal	3	114034
Terminal sleeve	3	50228
Terminal plug contact	6	51196
Terminal plug insulator	2	43501
Terminal plug retainer	2	43701
Housing ferrule	1	78346
Housing flange	2	43500
Signal lamp switch to signal lamp cable assembly (L. H. D.)	1	43374
Signal lamp switch to signal lamp cable assembly (R. H. D.)	1	43514
Terminal	1	76547
Terminal sleeve	1	50228
Tail and signal lamp terminal plug	1	43702
Instrument lamp to fuse block cable assembly	1	43524
Terminal	2	114038
Ammeter to fuse block strap	1	43526
Sleeve	1	43527
Ammeter to starter switch cable assembly	1	43363
Terminal, large	1	114041
Terminal, small	1	114038
Generator relay to ammeter cable assembly (magneto ignition)	1	43506
Terminal	2	114038
Terminal sleeve	2	50228
Horn switch to horn cable connector cable assembly	1	75963
Horn to horn switch connector cable assembly (L. H. D.)	1	43370
Horn to horn switch connector cable assembly (R. H. D.)	1	43510
Terminal	1	114038
Terminal sleeve	1	50228
Horn to fuse block cable assembly	1	43368
Terminal	2	114038

## BODY—OPEN CARS

## BODY HOLD-DOWN BOLTS

PART NAME	Per Car	Part Number
Body hold-down bolt No. 1	2	38786
Body hold-down bolt No. 2 (Touring)	2	38785
Body hold-down bolt Nos. 2, 3 and 4 (Roadster)	6	67899
Body hold-down bolt No. 4 (Touring)	2	38786
Body hold-down bolt No. 5 (Roadster)	2	87195
Bolt nut (Touring)	6	102635
Bolt lockwasher (Touring)	10	108580
Bolt nut (Roadster)	4	102635
Bolt lockwasher (Roadster)	10	108580
Body hold-down bolt No. 2 washer	2	39695
Body shim	as reqd.	84828
Body sill anti-squeak liner	2	37162
Body hold-down bolt No. 1 to chassis frame shim	2	84915

## SHROUD PROTECTOR STRIP

Body shroud protector strip	2	38769
Rivet	30	104409

## TOE BOARD

Toe board (L. H. D.)	1	46941
Toe board (R. H. D.)	1	93580
Screw (toe board to support)	4	105923
Bolt and nut (toe board to dash)	3	117209
Lockwasher (L. H. D.)	3	103319
Toe board pedal slot pad (L. H. D.)	1	46949
Toe board pedal slot pad (R. H. D.)	1	46948
Screw	4	105923

## FLOOR BOARDS

Front floor front board assembly	1	46943
Screw	4	101933
Front floor board battery cover	1	69837
Front floor board gear shift hole pad	1	46950
Screw	4	105923

## FLOOR MATS AND CARPET

Front floor mat (Touring) (L. H. D.)	1	46952
Front floor mat (Touring) (R. H. D.)	1	46951
Front floor mat (Roadster) (L. H. D.)	1	46954
Front floor mat (Roadster) (R. H. D.)	1	46953
Rear floor carpet (Touring)	1	94338

## INSTRUMENT PANEL

Instrument panel cover assembly (L. H. D.)	1	93568
Instrument panel cover assembly (R. H. D.)	1	93567
Rivet	14	106187

## BODY—OPEN CARS (Continued)

## BODY DOORS (TOURING)

PART NAME	Per Car	Part Number
Front door assembly, right (trimmed, with hardware, and finished) . . . . .	1	47271
Front door assembly, left (trimmed, with hardware, and finished) . . . . .	1	47272
Rear door assembly, right (trimmed, with hardware, and finished) . . . . .	1	47273
Rear door assembly, left (trimmed, with hardware, and finished) . . . . .	1	47274
Front door assembly, right (trimmed, with hardware, but in prime) . . . . .	1	47275
Front door assembly, left (trimmed, with hardware, but in prime) . . . . .	1	47276
Rear door assembly, right (trimmed, with hardware, but in prime) . . . . .	1	47277
Rear door assembly, left (trimmed, with hardware, but in prime) . . . . .	1	47278
Front door assembly, right (not trimmed, less hardware, in prime) . . . . .	1	91966
Front door assembly, left (not trimmed, less hardware, in prime) . . . . .	1	91967
Rear door assembly, right (not trimmed, less hardware, in prime) . . . . .	1	46665
Rear door assembly, left (not trimmed, less hardware, in prime) . . . . .	1	46666

## BODY DOORS (ROADSTER)

Door assembly, right (trimmed, with hardware, and finished) . . . . .	1	47283
Door assembly, left (trimmed, with hardware, and finished) . . . . .	1	47284
Door assembly, right (trimmed, with hardware, but in prime) . . . . .	1	47285
Door assembly, left (trimmed, with hardware, but in prime) . . . . .	1	47286
Door assembly, right (not trimmed, less hardware, in prime) . . . . .	1	91966
Door assembly, left (not trimmed, less hardware, in prime) . . . . .	1	91967

## DOOR HANDLES

Door outside handle (Touring) . . . . .	4	46938
Screw . . . . .	8	106189
Door outside handle (Roadster) . . . . .	2	46938
Screw . . . . .	4	106189
Door inside handle, right (Touring) . . . . .	2	57163
Door inside handle, left (Touring) . . . . .	2	57164
Screw . . . . .	4	57349
Lockwasher . . . . .	4	106497
Door inside handle, right (Roadster) . . . . .	1	57163
Door inside handle, left (Roadster) . . . . .	1	57164
Screw . . . . .	2	57349
Lockwasher . . . . .	2	106497

## DOOR LOCKS

Door lock assembly (Touring) . . . . .	4	66159
Side screw . . . . .	8	101919
Face screw . . . . .	8	10205
Door lock assembly (Roadster) . . . . .	2	66159
Side screw . . . . .	4	101919
Face screw . . . . .	4	102051

## DOOR HINGES

Door hinge, right (body half) (Touring) . . . . .	4	38749
Door hinge, left (body half) (Touring) . . . . .	4	38750
Door hinge, right (door half) (Touring) . . . . .	4	38496

## BODY—OPEN CARS (Continued)

## DOOR HINGES (Continued)

PART NAME	Per Car	Part Number
Door hinge, left (door half) (Touring) . . . . .	4	38497
Screw . . . . .	12	101933
Bolt and nut (front door hinge to body) . . . . .	16	101353
Door hinge, right (body half) (Roadster) . . . . .	2	38749
Door hinge, left (body half) (Roadster) . . . . .	2	38750
Door hinge, right (door half) (Roadster) . . . . .	2	38496
Door hinge, left (door half) (Roadster) . . . . .	2	38497
Screw . . . . .	8	101933
Bolt and nut (front door hinge to body) . . . . .	4	101353

## DOOR BUMPER

Door rubber bumper (Touring) . . . . .	6	83325
Screw . . . . .	6	106157
Door rubber bumper (Roadster) . . . . .	4	83325
Screw . . . . .	4	106157
Door dovetail (male) (Touring) . . . . .	4	83486
Screw . . . . .	8	101932
Door dovetail (male) (Roadster) . . . . .	2	101932
Screw . . . . .	4	101932
Front door stop assembly, right . . . . .	1	90541
Front door stop assembly, left . . . . .	1	90542
Rear door stop assembly, right (Touring) . . . . .	1	92039
Rear door stop assembly, left (Touring) . . . . .	1	92040
Screw (Touring) . . . . .	20	101935
Screw (Roadster) . . . . .	12	101935

## SEAT CUSHIONS

Front seat cushion assembly (Touring) . . . . .	1	94339
Rear seat cushion assembly (Touring) . . . . .	1	94340
Rear seat back assembly (Touring) . . . . .	1	94341
Front seat cushion assembly (Roadster) . . . . .	1	94399
Rumble seat cushion assembly (Roadster) . . . . .	1	94325

## ROBE STRAP (TOURING)

Robe strap assembly . . . . .	1	83725
Screw . . . . .	2	106212

## FOOT REST (TOURING)

Foot rest assembly . . . . .	1	89098
Screw . . . . .	4	108953

## REAR DECK AND COMPARTMENT (ROADSTER)

Back lid hinge assembly, right . . . . .	1	91181
Back lid hinge assembly, left . . . . .	1	91182
Bolt and nut . . . . .	6	101394
Plain washer . . . . .	6	106262
Adjusting screw . . . . .	2	93400
Nut . . . . .	2	103061

## BODY—OPEN CARS (Continued)

## REAR DECK AND COMPARTMENT (ROADSTER) (Continued)

PART NAME	Per Car	Part Number
Deck lid lock.....	1	93693
Deck lid lock screw.....	4	101933
Deck lid lock key.....	1	
Deck lid handle assembly.....	1	92680
Deck lid handle screw.....	2	106189
Deck lid bumper.....	2	92249
Deck cleat (inner).....	2	92685
Deck cleat (outer).....	2	92686
Deck cleat screw.....	4	107118
Deck cleat screw nut.....	4	103089
Deck cleat screw plain washer.....	4	103359
Deck cleat screw lockwasher.....	4	106498

## REAR COMPARTMENT TREAD PLATES (ROADSTER)

Rear compartment fender tread plate.....	1	93363
Washer (leather).....	2	93364
Nut.....	2	114523
Screw lockwasher.....	2	
Rear compartment fender tread plate bracket.....	1	93446
Rear compartment fender tread plate bracket, lower.....	1	93523
Screw.....	2	100123
Screw washer.....	2	106263
Rear compartment chassis tread plate (L. H. D.).....	1	

## WINDSHIELD

Windshield assembly (Touring) (L. H. D.).....	1	92942
Windshield assembly (Touring) (R. H. D.).....	1	92941
Windshield assembly (Roadster) (L. H. D.).....	1	46594
Windshield assembly (Roadster) (R. H. D.).....	1	46593
Windshield side arm, right (Touring).....	1	92943
Windshield side arm, left (Touring).....	1	92944
Windshield side arm, right (Roadster) (L. H. D.).....	1	47306
Windshield side arm, left (Roadster) (L. H. D.).....	1	46587
Windshield side arm, right (Roadster) (R. H. D.).....	1	46586
Windshield side arm, left (Roadster) (R. H. D.).....	1	47307
Windshield side arm pad, right.....	1	93514
Windshield side arm pad, left.....	1	93515

## WINDSHIELD WIPER

Windshield wiper assembly (L. H. D.).....	1	43704*
Windshield wiper assembly (R. H. D.).....	1	43705*

## REAR VIEW MIRROR

Rear view mirror assembly.....	1	82523
Rear view mirror glass.....	1	82524
Fastening bolt.....	2	107729
Fastening bolt nut.....	2	110923
Fastening bolt washer.....	2	103452

\*Served by Trico Products Corp., Buffalo, N. Y.

## BODY—OPEN CARS (Continued)

## TOP ASSEMBLY

PART NAME	Per Car	Part Number
Top assembly with side curtains (Touring).....	1	94352
Top assembly with side curtains (Roadster).....	1	94377
Top assembly less side curtains (Touring).....	1	94353
Top assembly less side curtains (Roadster).....	1	94378

## TOP MATERIALS

Top deck material (Touring).....	as reqd.	15294
Top side curtain material (Touring).....	as reqd.	15293
Top deck material (Roadster).....	as reqd.	68144
Top side curtain material (Roadster).....	as reqd.	68144
Binding (3/4" two-fold bias pebble grain, bright finish) (Touring).....	as reqd.	37199
Binding (5/8" double cord hidem long grain, bright finish) (Touring).....	as reqd.	36559
Binding (3/8" two-fold long grain, bright finish) (Touring).....	as reqd.	37749
Binding (3/4" two-fold bias, bright finish) (Touring).....	as reqd.	15331
Binding (3/4" two-fold bias) (Roadster).....	as reqd.	89879
Binding (5/8" two-fold hidem) (Roadster).....	as reqd.	89880
Binding (3/8" two-fold straight) (Roadster).....	as reqd.	89881
Binding (3/4" two-fold straight) (Roadster).....	as reqd.	89279
Binding (finish end).....	as reqd.	115580

## TOP DECK AND SIDE QUARTERS

Top deck and side quarters (Touring).....	1	93461
Top deck and side quarters (Roadster).....	1	94386

## SIDE CURTAINS

Front side curtain, right (Touring).....	1	94367
Front side curtain, left (Touring).....	1	94368
Front side curtain, right (Roadster).....	1	94393
Front side curtain, left (Roadster).....	1	94394
Center side curtain, right (Touring).....	1	94369
Center side curtain, left (Touring).....	1	94370
Rear side curtain, right (Touring).....	1	94371
Rear side curtain, left (Touring).....	1	94372
Rear side curtain, right (Roadster).....	1	94395
Rear side curtain, left (Roadster).....	1	94396

## CURTAIN ROD

Curtain carrier rod (Touring).....	4	47321
Curtain carrier rod (Roadster).....	2	93547
Curtain carrier rod clip (Touring).....	4	61214
Curtain carrier rod clip (Roadster).....	2	61214
Curtain carrier rod socket (Touring).....	4	90487
Curtain carrier rod socket (Roadster).....	2	90487



## BODY—OPEN CARS (Continued)

## BACK CURTAIN

PART NAME	Per Car	Part Number
Back and gypsy curtain assembly (Touring)	1	94358
Gypsy curtain assembly, right (Roadster)	1	94381
Gypsy curtain assembly, left (Roadster)	1	94382
Back curtain assembly (Roadster)	1	94383
Back curtain light assembly (Roadster)	1	83654
Back curtain glass	1	83620
Back curtain glass frame (outer)	1	83622
Back curtain glass frame (inner)	1	83621
Screw	2	83653
Back curtain light assembly (Touring)	1	A-9717

## TOP TO WINDSHIELD BRACKET

Top to windshield bracket, right (Touring)	1	63416
Top to windshield bracket, left (Touring)	1	63417
Top to windshield bracket, right (Roadster)	1	83601
Top to windshield bracket, left (Roadster)	1	83602
Bolt and nut	4	115559
Bolt lockwasher	4	103319

## TOP PROP NUT

Top prop nut	2	120335
Top prop nut washer	2	65635

## TOP REST AND SUPPORT

Top rest bracket support, right	1	92889
Top rest bracket support, left	1	92890
Top bow rest assembly (Touring)	2	47293
Top bow rest bracket (Touring)	2	92886
Top support bracket, right	1	91264
Top support bracket, left	1	91265
Screw	8	101943
Top rest assembly (Roadster)	2	83457
Top rest	2	83458
Top rest retaining spring	2	83460
Top rest retaining rivet	2	83459
Top hold-down strap assembly	1	65611

## TOP BOOT (For Service Only)

Top boot assembly (Touring)	1	94375
Top boot assembly (Roadster)	1	94397

## TRIMMING MATERIALS

Leather hide	as reqd.	46962
Leather trim cloth (light weight)	as reqd.	46963
Leather trim cloth (heavy weight)	as reqd.	46964
Binding ( $\frac{3}{8}$ " two-cord hidem)	as reqd.	46965
Binding ( $\frac{3}{4}$ " two-fold bias to match leather)	as reqd.	46966
Binding ( $\frac{3}{8}$ " two-fold straight)	as reqd.	46969
Binding ( $1\frac{1}{4}$ " single-fold)	as reqd.	46967

## BODY—CLOSED CARS†

## BODY SHROUD PROTECTOR STRIP

PART NAME	Per Car	Part Number
Body shroud protector strip	2	38769
Rivet	30	104409
Body shim	as reqd.	84828
Body sill anti-squeak liner	2	37162

## FLOOR MATS AND FELTS

Front floor mat (Two-door Sedan) (L. H. D.)	1	47387
Front floor mat (Two-door Sedan) (R. H. D.)	1	47386
Front floor mat (Four-door Sedan) (L. H. D.)	1	47389
Front floor mat (Four-door Sedan) (R. H. D.)	1	47388
Front floor mat (Coupe) (L. H. D.)	1	46958
Front floor mat (Coupe) (R. H. D.)	1	46957

## INSTRUMENT PANEL

Instrument panel cover assembly (L. H. D.)	1	93570*
Instrument panel cover assembly (R. H. D.)	1	93569*

## REAR VIEW MIRROR

Rear view mirror assembly	1	82523
Rear view mirror glass	1	82524
Bolt	2	107729
Nut	2	110923
Washer	2	103452

\*Instrument panel covers will only be serviced with a new car serial number plate attached. All orders must be accompanied with an affidavit properly executed, proving loss or damage. In case of damage, old serial number plate must be returned.

†Parts listed on this page consist of only such parts as are furnished by the Plymouth Motor Corporation for use on closed body types furnished by the Briggs Manufacturing Company. A complete Parts and Price List for these bodies may be found in the following pages.

Briggs Bodies

# Parts and Price List

for

CHRYSLER  
PLYMOUTH

FOUR-DOOR SEDAN  
TWO-DOOR SEDAN  
COUPE

(Prices Subject to Change Without Notice)

**Briggs Manufacturing Company**  
11631 Mack Avenue  
Detroit, Michigan

PRINTED IN U.S.A.

Order parts for Briggs Bodies  
 direct from Service Parts De-  
 partment, Briggs Manufacturing  
 Company, 11631 Mack Avenue,  
 Detroit, Michigan

It is imperative when ordering parts to give body number as well as the  
 model number on the order

All prices F. O. B. Detroit, Michigan

All prices subject to change without notice

PLYMOUTH PARTS AND PRICE LIST

PLYMOUTH FOUR-DOOR SEDAN  
 Briggs Manufacturing Co. Model 320

Part Number	PART NAME	No. Req.	Price Each
<b>WINDSHIELD</b>			
110716	Windshield glass and channel assembly . . . . .	1	\$16.50
100709	Windshield upper sash channel assembly . . . . .	1	1.00
110706	Windshield side sash channel, right hand . . . . .	1	.50
110707	Windshield side sash channel, left hand . . . . .	1	.50
100598	Windshield weatherstrip retainer (upper) . . . . .	1	.50
110586	Windshield weatherstrip retainer (lower) . . . . .	1	.65
110702	Windshield side sash channel filler . . . . .	2	.15
110708	Windshield side sash channel runway, right hand . . . . .	1	.65
110709	Windshield side sash channel runway, left hand . . . . .	1	.65
110710	Windshield glass . . . . .	1	13.50
110712	Windshield weatherstrip (lower) . . . . .	1	.60
100713	Windshield weatherstrip (upper) . . . . .	1	.25
<b>WINDSHIELD REGULATOR</b>			
110958	Windshield regulator board trimmed and with regulator assembled (less windshield wiper) . . . . .	1	7.50
110070	Windshield regulator board (less regulator trimming and wind- shield wiper) . . . . .	1	1.75
110720	Windshield regulator assembly . . . . .	1	5.00
110640	Windshield regulator handle . . . . .	1	1.25
112640	Windshield regulator handle escutcheon plate . . . . .	1	.25
30617	Windshield regulator handle pin . . . . .	1	.10
40672	Windshield regulator handle spring . . . . .	1	.10
<b>SUNSHADE</b>			
110570	Sunshade . . . . .	1	5.25
<b>WINDSHIELD WIPER</b>			
110714	Windshield wiper tube . . . . .	1	.25
100711	Windshield wiper bracket . . . . .	1	.25
<b>INSTRUMENT BOARD</b>			
Instrument board assembly furnished by the Plymouth Motor Corporation.			
<b>VENTILATOR ADJUSTER</b>			
100414	Windshield ventilator adjuster assembly . . . . .	4	.35
100415	Windshield ventilator adjuster ferrule . . . . .	4	.15
100417	Windshield ventilator adjuster lock screw . . . . .	4	.05
100416	Windshield ventilator adjuster plate assembly . . . . .	4	.15
<b>DOORS</b>			
110986	Door assembly complete, right front, painted and trimmed with all hardware and glass . . . . .	1	65.00
110987	Door assembly complete, left front, painted and trimmed with all hardware and glass . . . . .	1	65.00
110988	Door assembly complete, right rear, painted and trimmed with all hardware and glass . . . . .	1	65.00

PLYMOUTH FOUR-DOOR SEDAN (Continued)  
Briggs Manufacturing Co. Model 320 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOORS (Continued)</b>			
110989	Door assembly complete, left rear, painted and trimmed with all hardware and glass.	1	\$65.00
111302	Door assembly, right front, not painted or trimmed and less all hardware and glass.	1	28.50
110303	Door assembly, left front, not painted or trimmed and less all hardware and glass.	1	28.50
110304	Door assembly, right rear, not painted or trimmed and less all hardware and glass.	1	28.50
110305	Door assembly, left rear, not painted or trimmed and less all hardware and glass.	1	28.50
<b>DOOR WINDOWS</b>			
110646	Front door window assembly, right (consists of glass assembled in channel).	1	7.50
110647	Front door window assembly, left (consists of glass assembled in channel).	1	7.50
110650	Rear door window assembly (consists of glass assembled in channel), right hand.	1	7.50
110651	Rear door window assembly, left hand.	1	7.50
110496	Front door window glass channel, right.	1	.75
110497	Front door window glass channel, left.	1	.75
110492	Rear door window glass channel, right.	1	.75
110493	Rear door window glass channel, left.	1	.75
110676	Door window glass, front.	2	6.00
110677	Door window glass, rear.	2	6.00
110668	Front door header weatherstrip.	2	.40
110667	Rear door header weatherstrip.	2	.40
110657	Front door window glass runway.	4	.65
103658	Rear door window glass runway.	4	.65
<b>DOOR WINDOW WEATHERSTRIP</b>			
110600	Front door belt weatherstrip retainer.	2	.30
110601	Rear door belt weatherstrip retainer.	2	.25
110622	Door window belt weatherstrips.	4	.10
110660	Front door glass channel filler.	2	.15
110661	Rear door glass channel filler.	2	.15
<b>FINISH MOULDINGS</b>			
110480	Front door belt finish moulding, right.	1	.90
110481	Front door belt finish moulding, left.	1	.90
110482	Rear door belt finish moulding.	2	.80
110484A	Front door upper finish moulding, right.	1	1.90
110485A	Front door upper finish moulding, left.	1	1.90
110467A	Rear door upper finish moulding.	2	1.75

PLYMOUTH FOUR-DOOR SEDAN (Continued)  
Briggs Manufacturing Co. Model 320 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOOR HINGES</b>			
110520	Front door hinge assembly, upper, right hand.	1	\$ 1.40
110521	Front door hinge assembly, upper, left hand.	1	1.40
110522	Front door hinge assembly, center, right hand.	1	1.40
110523	Front door hinge assembly, center, left hand.	1	1.40
110524	Front door hinge assembly, lower, right hand.	1	1.40
110525	Front door hinge assembly, lower, left hand.	1	1.40
110526	Rear door hinge assembly, upper, left hand.	1	1.40
110527	Rear door hinge assembly, upper, right hand.	1	1.40
110528	Rear door hinge assembly, center, right hand.	1	1.40
110529	Rear door hinge assembly, center, left hand.	1	1.40
110530	Rear door hinge assembly, lower, right hand.	1	1.40
110531	Rear door hinge assembly, lower, left hand.	1	1.40
<b>DOOR LOCKS AND HANDLES</b>			
100616	Front door lock assembly, right.	1	1.45
100617	Door lock assembly, front left and rear right.	2	1.45
100618	Door lock assembly, rear left.	1	1.45
110608	Remote control assembly, front right.	1	.55
110609	Remote control assembly, front left.	1	.55
110610	Remote control assembly, rear right.	1	.55
110611	Remote control assembly, rear left.	1	.55
110687	Door lock outside handle assembly.	3	1.60
110686	Door lock outside locking handle assembly.	1	2.50
112640	Remote control escutcheon.	4	.25
110642	Remote control handle.	4	.90
110690	Door lock striker plate.	4	.15
30617	Remote handle spring.	4	.10
100644	Door lock safety screw.	4	.08
110688	Door lock key (show numbers).	2 net	.25
40672	Remote handles escutcheon pin.		.10
<b>DOOR BUMPERS</b>			
34647	Door bumper retainer.	8	.10
34648	Door bumpers.	8	.15
100507	Door dovetail wedge plate assembly.	4	.22
100518	Door dovetail casing assembly.	4	.75
<b>DOOR CHECKS</b>			
49546	Door check strap grommet, rear.	2	.10
50913	Door check strap dog plate.	4	.10
50912	Door check strap, front.	2	.50
34919	Door check strap, rear.	2	.50
78482	Door check strap plate.	2	.10
50436	Door check strap grommet, front.	2	.10

## PLYMOUTH FOUR-DOOR SEDAN (Continued)

Briggs Manufacturing Co. Model 320 (Continued)

## DOOR WINDOW REGULATOR

Part Number	PART NAME	No. Req.	Price Each
49664	Door window regulator assembly, right	2	\$2.10
49665	Door window regulator assembly, left	2	2.10
110641	Door window regulator handle	4	1.50
40672	Door window regulator handle pin	4	.10
112640	Door window regulator escutcheon	4	.25
30617	Door window regulator escutcheon spring		.10

## REAR QUARTER WINDOW

110648	Rear quarter window assembly (consists of glass assembled in channel), right	1	7.50
110649	Rear quarter window assembly (consists of glass assembled in channel), left	1	7.50
110498	Rear quarter window glass channel, right	1	.75
110499	Rear quarter window glass channel, left	1	.75
110678	Rear quarter window glass	1	6.00
110669	Rear quarter window header weatherstrip	2	.40
110659	Rear quarter window glass runway	2	.65

## REAR QUARTER WINDOW WEATHERSTRIP

110602	Rear quarter belt weatherstrip retainer	2	.30
110622	Rear quarter belt weatherstrip	2	.10
110662	Rear quarter glass channel filler	2	.10

## REAR QUARTER WINDOW FINISH MOULDING

110483	Rear quarter finish moulding belt	2	.80
110494	Rear quarter finish moulding assembly (upper right)	2	1.90
110495	Rear quarter finish moulding assembly (upper left)	2	1.90

## REAR QUARTER WINDOW REGULATORS

49664	Rear quarter window regulator assembly, right	1	2.10
49665	Rear quarter window regulator assembly, left	1	2.10
110643	Rear quarter window regulator handle	2	1.50
112640	Rear quarter window regulator handle escutcheon plate	2	.30
40672	Rear quarter window regulator handle pin	2	.10
30617	Rear quarter window regulator handle spring	2	.10

## REAR WINDOW

110679	Rear window glass	1	3.50
110625	Rear window channel rubber (top and bottom)	2	.40
110624	Rear window channel rubber (sides)	2	.25

## CURTAIN AND ROLLER

100753	Rear window curtain assembly complete	1	3.75
100752	Rear window curtain roller assembly	1	1.25

## DOME LIGHT

110783	Dome light and switch assembly (less bulbs)	1	2.00
110784	Dome light lens	1	.50

## PLYMOUTH FOUR-DOOR SEDAN (Continued)

Briggs Manufacturing Co. Model 320 (Continued)

## FOOT REST

Part Number	PART NAME	No. Req.	Price Each
100635	Foot rest assembly	1	\$ 3.00

## ROBE RAIL ASSEMBLY

100630	Robe rail assembly	1	2.00
--------	--------------------	---	------

## FRONT SEAT CUSHIONS AND SPRINGS

110932	Front seat cushion assembly	1	32.50
110941	Front seat back cushion assembly	1	45.00
110820	Front seat cushion spring	1	5.50
110822	Front seat back spring	1	3.75

## REAR SEAT CUSHION AND SPRINGS

110936	Rear seat cushion assembly	1	32.50
110947	Rear seat back cushion assembly	1	30.00
110821	Rear seat cushion spring	1	5.50
110823	Rear seat back spring	1	4.25

## CARPETS

110985	Rear floor carpet	1	6.00
--------	-------------------	---	------

## HEADLINING

110953	Headlining and listing assembly	1	4.50
--------	---------------------------------	---	------

## DECK COVERING

110872	Top deck	1	5.00
--------	----------	---	------

## PLYMOUTH TWO-DOOR SEDAN

Briggs Manufacturing Co. Model 321

Part Number	PART NAME	No. Req.	Price Each
<b>WINDSHIELD</b>			
110716	Windshield glass and channel assembly	1	\$16.50
100709	Windshield upper sash channel assembly	1	1.00
110706	Windshield side sash channel, right hand	1	.50
110707	Windshield side sash channel, left hand	1	.50
100598	Windshield weatherstrip retainer (upper)	1	.50
110586	Windshield weatherstrip retainer (lower)	1	.65
110702	Windshield side sash channel filler	2	.15
110708	Windshield side sash channel runway, right hand	1	.65
110709	Windshield side sash channel runway, left hand	1	.65
110710	Windshield glass	1	13.50
110712	Windshield weatherstrip (lower)	1	.60
110713	Windshield weatherstrip (upper)	1	.25
<b>WINDSHIELD REGULATOR</b>			
113958	Windshield regulator board trimmed and with regulator assembled (less windshield wiper)	1	7.50
110070	Windshield regulator board (less regulator trimming and windshield wiper)	1	1.75
110720	Windshield regulator assembly	1	5.00
110640	Windshield regulator handle	1	1.25
112640	Windshield regulator handle escutcheon plate	1	.25
40672	Windshield regulator handle pin		.10
30617	Windshield regulator handle spring		.10
<b>SUNSHADE</b>			
110570	Sunshade	1	5.25
<b>WINDSHIELD WIPER</b>			
110714	Windshield wiper tube	1	.25
100711	Windshield wiper bracket	1	.25
<b>INSTRUMENT BOARD</b>			
Instrument board assembly furnished by the Plymouth Motor Corporation.			
<b>VENTILATOR ADJUSTER</b>			
100414	Windshield ventilator adjuster assembly	4	.35
100415	Windshield ventilator adjuster ferrule	4	.15
100416	Windshield ventilator adjuster plate assembly	4	.15
100417	Windshield ventilator adjuster lock screw	4	.05
<b>DOORS</b>			
112994	Door assembly complete, right hand, painted, trimmed with all hardware and glass	1	80.00
112995	Door assembly complete, left hand, painted, trimmed with all hardware and glass	1	80.00
112302	Door assembly, right, not painted or trimmed (less all hardware and glass)	1	35.00
112303	Door assembly, left, not painted or trimmed (less all hardware and glass)	1	35.00

## PLYMOUTH TWO-DOOR SEDAN (Continued)

Briggs Manufacturing Co. Model 321 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOOR WINDOWS</b>			
112646	Door window glass and channel assembly, right	1	\$10.00
112647	Door window glass and channel assembly, left	1	10.00
112496	Door window glass and channel, right	1	.85
112497	Door window glass and channel, left	1	.85
112676	Door window glass	2	8.50
110657	Door window glass runway	4	.65
112660	Door and side glass filler		.10
<b>DOOR WINDOW WEATHERSTRIP</b>			
112600	Door belt weatherstrip retainer	2	.30
112622	Door window belt weatherstrip	2	.10
112660	Door glass channel filler	2	.10
<b>FINISH MOULDING</b>			
112480	Door belt finish moulding, right	1	.85
112481	Door belt finish moulding, left	1	.85
112484	Door upper finish moulding, right	1	2.00
112485	Door upper finish moulding, left	1	2.00
<b>DOOR HINGES</b>			
110520	Front door hinge assembly, right hand (upper)	1	1.40
110521	Front door hinge assembly, left hand (upper)	1	1.40
110522	Front door hinge assembly, right hand (center)	1	1.40
110523	Front door hinge assembly, left hand (center)	1	1.40
110524	Front door hinge assembly, right hand (lower)	1	1.40
110525	Front door hinge assembly, left hand (lower)	1	1.40
<b>DOOR LOCKS AND HANDLES</b>			
100616	Right hand door lock assembly	1	1.45
100617	Left hand door lock assembly	1	1.45
112614	Remote control, right hand	1	.55
112615	Remote control, left hand	1	.55
110687	Door lock outside handle assembly	1	1.60
110686	Door lock outside locking handle assembly	1	2.50
112640	Remote control escutcheon	2	.25
110642	Remote control handle	2	.90
110688	Door lock key (show numbers)	2	net .25
110690	Door lock striker plate	2	.15
40672	Remote handle pin	2	.10
100644	Door lock safety screw	4	.10
30617	Remote handle spring		
<b>DOOR BUMPERS</b>			
34647	Door bumper retainer	2	.10
34648	Door bumpers	2	.15
100507	Door dovetail wedge plate assembly, male	2	.22
100518	Door dovetail casing assembly, female	2	.75

PLYMOUTH TWO-DOOR SEDAN (Continued)  
Briggs Manufacturing Co. Model 321 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOOR CHECKS</b>			
50912	Door check strap.....	2	\$ .50
50913	Door check strap dog plate.....	2	.10
50436	Door check strap grommet.....	2	.10
78482	Door check strap guide.....	2	.10
<b>DOOR WINDOW REGULATORS</b>			
112664	Door window regulator assembly, right.....	1	2.50
112665	Door window regulator assembly, left.....	1	2.50
110641	Door window regulator handle.....	2	1.50
40672	Door window regulator handle pin.....	2	.10
112640	Door window regulator escutcheon.....	2	.30
30617	Door window regulator escutcheon spring.....		.10
<b>SIDE WINDOW</b>			
112648	Side window and glass channel assembly, right.....	1	10.00
112649	Side window and glass channel assembly, left.....	1	10.00
112496	Side window glass channel, right.....		.85
112497	Side window glass channel, left.....		.85
112673	Side window glass.....	2	8.50
112668	Side window header weatherstrip.....	2	.40
110657	Side window glass runway.....	2	.65
<b>SIDE WINDOW WEATHERSTRIP</b>			
112600	Side window belt weatherstrip retainer.....	2	.30
112622	Side window belt weatherstrip.....	2	.10
112660	Side window glass channel filler.....	2	.10
<b>SIDE WINDOW FINISH MOULDINGS</b>			
112482	Side window finish moulding belt.....	2	.85
112494	Side window finish moulding assembly (upper right).....	1	2.00
112495	Side window finish moulding assembly (upper left).....	1	2.00
<b>SIDE WINDOW REGULATOR</b>			
49664	Side window regulator assembly, right hand.....	1	2.10
49665	Side window regulator assembly, left hand.....	1	2.10
110643	Side window regulator handle.....	2	1.50
112640	Side window regulator escutcheon plate.....	2	.30
40672	Side window regulator handle pin.....	2	.10
30617	Side window regulator handle spring.....	2	.15
<b>REAR WINDOW</b>			
110679	Rear window glass.....	1	3.50
110625	Rear window channel rubber (top and bottom).....	2	.40
110624	Rear window channel rubber (sides).....	2	.25
<b>CURTAIN AND ROLLER</b>			
100753	Rear window curtain assembly complete.....	1	3.75
100752	Rear window curtain roller assembly.....	1	1.25

PLYMOUTH TWO-DOOR SEDAN (Continued)  
Briggs Manufacturing Co. Model 321 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOME LIGHT</b>			
110783	Dome light and switch assembly (less bulbs).....	1	\$ 2.00
110784	Dome light lens.....	1	.40
<b>FRONT SEATS</b>			
112989	Driver's seat and back assembly, trimmed, complete.....	1	37.50
112990	Driver's seat cushion assembly.....	1	22.50
111991	Driver's seat back assembly.....	1	15.00
112989	Passenger's seat and back assembly, trimmed, complete.....	1	37.50
112990	Passenger's seat cushion assembly.....	1	22.50
112991	Passenger's seat back assembly.....	1	15.00
<b>REAR SEAT CUSHION AND SPRING</b>			
110936	Rear seat cushion assembly.....	1	32.50
110947	Rear seat back cushion assembly.....	1	30.00
110821	Rear seat cushion spring.....	1	5.50
110833	Rear seat back spring.....	1	3.75
<b>CARPET</b>			
112899	Rear floor carpet.....	1	7.50
<b>DECK COVERING</b>			
112848	Top deck.....	1	5.25
<b>TRIM</b>			
112880	Driver's and auxiliary seat back cover only.....	2	3.00
112881	Headlinings and listing assembly.....	1	4.50

**PLYMOUTH COUPE**  
Briggs Manufacturing Co. Model 322

Part Number	PART NAME	No. Req.	Price Each
<b>WINDSHIELD</b>			
110716	Windshield glass and channel assembly	1	\$16.50
100709	Windshield upper sash channel assembly	1	1.00
110706	Windshield side sash channel, right hand	1	.50
110707	Windshield side sash channel, left hand	1	.50
100598	Windshield weatherstrip retainer (upper)	1	.50
110586	Windshield weatherstrip retainer (lower)	1	.65
110702	Windshield side sash channel filler	2	.15
110708	Windshield side sash channel runway, right hand	1	.65
110709	Windshield side sash channel runway, left hand	1	.65
110710	Windshield glass	1	13.50
110712	Windshield weatherstrip (lower)	1	.60
100713	Windshield weatherstrip (upper)	1	.25
<b>WINDSHIELD REGULATOR</b>			
113958	Windshield regulator board trimmed and with regulator assembled (less windshield wiper)	1	7.50
110070	Windshield regulator board (less regulator trimming and windshield wiper)	1	1.75
110720	Windshield regulator assembly	1	5.00
110640	Windshield regulator handle	1	1.25
112640	Windshield regulator handle escutcheon plate	1	.25
30617	Windshield regulator handle escutcheon spring		.10
40672	Windshield regulator handle escutcheon pin		.10
<b>SUNSHADE</b>			
110570	Sunshade (untrimmed)	1	5.25
<b>WINDSHIELD WIPER</b>			
110714	Windshield wiper tube	1	.25
100711	Windshield wiper bracket	1	.25
<b>INSTRUMENT BOARD</b>			
Instrument board assembly furnished by the Plymouth Motor Corporation.			
<b>VENTILATOR ADJUSTER</b>			
100414	Windshield ventilator adjuster assembly	4	.35
100415	Windshield ventilator adjuster ferrule	4	.15
100416	Windshield ventilator adjuster plate assembly	4	.15
100417	Windshield ventilator adjuster lock screw	4	.05
<b>DOORS</b>			
113994	Door assembly complete, right hand, painted and trimmed with hardware and glass	1	80.00
113995	Door assembly complete, left hand, painted and trimmed with all hardware and glass	1	80.00
113302	Door assembly, right hand, not painted or trimmed (less all hardware and glass)	1	35.00
113303	Door assembly, left hand, not painted or trimmed (less all hardware and glass)	1	35.00

**PLYMOUTH COUPE (Continued)**  
Briggs Manufacturing Co. Model 322 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOOR WINDOWS</b>			
113646	Door glass and channel assembly, right hand	1	\$10.00
113647	Door glass and channel assembly, left hand	1	10.00
113676	Door window glass	2	8.50
113496	Door window glass channel, right		.85
113497	Door window glass channel, left		.85
113668	Door header weatherstrip	2	.40
110657	Door window glass runway	4	.65
<b>DOOR WINDOW WEATHERSTRIP</b>			
103600	Door belt weatherstrip retainer	2	.30
103622	Door window belt weatherstrip	2	.10
113660	Door glass channel filler	2	.10
<b>FINISH MOULDINGS</b>			
113480	Door belt finish moulding, right	1	.80
113481	Door belt finish moulding, left	1	.80
113486	Door upper finish moulding, right	1	2.00
113487	Door finish moulding, left	1	2.00
<b>DOOR HINGES</b>			
110520	Door hinge assembly, upper, right hand	1	1.40
110521	Door hinge assembly, upper, left hand	1	1.40
110522	Door hinge assembly, center, right hand	1	1.40
110523	Door hinge assembly, center, left hand	1	1.40
110524	Door hinge assembly, lower, right hand	1	1.40
110525	Door hinge assembly, lower, left hand	1	1.40
<b>DOOR LOCKS AND HANDLES</b>			
100616	Door lock assembly, right hand	1	1.45
100617	Door lock assembly, left hand	1	1.45
110687	Door lock outside handle assembly	1	2.50
110686	Door lock outside locking handle assembly	1	1.60
112640	Remote control escutcheon	2	.25
110642	Remote control handle	2	.90
110690	Door lock striker plate	2	.15
100644	Door lock safety screw	2	.08
110688	Door and deck lock key (show numbers)	2	.25
103504	Deck hinge screw	2	.05
113693	Deck lock		.10
30617	Remote handle escutcheon spring		.10
40672	Remote handle escutcheon pin		.10
<b>DOOR BUMBERS</b>			
34647	Door bumper retainer	2	.10
34648	Door bumper	2	.15
100507	Door dovetail wedge plate assembly, male	2	.22
100518	Door dovetail casing assembly, female	2	.75



PLYMOUTH COUPE (Continued)  
Briggs Manufacturing Co. Model 322 (Continued)

Part Number	PART NAME	No. Req.	Price Each
<b>DOOR CHECKS</b>			
50913	Door check strap dog plate.....		\$ .10
50912	Door check strap, front.....		.50
24919	Door check strap, rear.....		.50
78482	Door check strap plate.....		.10
50436	Front door check strap grommet.....		.10
49546	Rear door check strap grommet.....		.10
<b>DOOR WINDOW REGULATORS</b>			
49664	Door window regulator assembly, right.....	1	2.10 <sup>4</sup>
49665	Door window regulator assembly, left.....	1	2.10
110641	Door window regulator handle.....	2	1.50
30617	Door window regulator handle spring.....	2	.10
112640	Door window regulator escutcheon.....	2	.25
40672	Door window regulator escutcheon pin.....	2	.10
<b>REAR WINDOW</b>			
110679	Rear window glass.....	1	3.50
110625	Rear window channel rubber (top and bottom).....	2	.40
110624	Rear window channel rubber (sides).....	2	.25
100753	Rear window curtain assembly complete.....	1	3.75
100752	Rear window curtain roller assembly.....	1	1.25
<b>CUSHION AND SPRINGS</b>			
113926	Seat cushion assembly complete.....	1	35.00
113937	Seat back cushion assembly complete.....	1	32.50
<b>TRIM</b>			
113847	Top deck.....	1	3.00
113924	Headlining and listing assembly.....	1	3.25
113976	Tool compartment cover.....	1	2.00

Speaker-Hines Printing Co.  
Detroit

